

Where Do I Find Everything I Need for Process Measurement and Control? **OMEGA...Of Course!**

TEMPERATURE

- ☑ Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- ☑ Wire: Thermocouple, RTD & Thermistor
- ☑ Calibrators & Ice Point References
- ☑ Recorders, Controllers & Process Monitors
- ☑ Infrared Pyrometers

PRESSURE, STRAIN AND FORCE

- ☑ Transducer & Strain Gauges
- ☑ Load Cells & Pressure Gauges
- ☑ Displacement Transducers
- ☑ Instrumentation & Accessories

FLOW/LEVEL

- ☑ Rotameters, Gas Mass Flowmeters & Flow Computers
- ☑ Air Velocity Indicators
- ☑ Turbine/Paddlewheel Systems
- ☑ Totalizers & Batch Controllers

pH/CONDUCTIVITY

- ☑ pH Electrodes, Testers & Accessories
- ☑ Benchtop/Laboratory Meters
- ☑ Controllers, Calibrators, Simulators & Pumps
- ☑ Industrial pH & Conductivity Equipment

DATA ACQUISITION

- ☑ Data Acquisition & Engineering Software
- ☑ Communications-Based Acquisition Systems
- ☑ Plug-in Cards for Apple, IBM & Compatibles
- ☑ Datalogging Systems
- ☑ Recorders, Printers & Plotters

HEATERS

- ☑ Heating Cable
- ☑ Cartridge & Strip Heaters
- ☑ Immersion & Band Heaters
- ☑ Flexible Heaters
- ☑ Laboratory Heaters

ENVIRONMENTAL MONITORING AND CONTROL

- ☑ Metering & Control Instrumentation
- ☑ Refractometers
- ☑ Pumps & Tubing
- ☑ Air, Soil & Water Monitors
- ☑ Industrial Water & Wastewater Treatment
- ☑ pH, Conductivity & Dissolved Oxygen Instruments

search by:

 Part Number All Omega

 ORDER BY PART NUMBER
IF YOU KNOW THE PART
NUMBER YOU WISH TO ORDER

[PRODUCT MANUALS](#)
[TECHNICAL REFERENCE](#)
[CALIBRATION SERVICES](#)
[FTP SITE](#)
[E-QUOTE](#)
[PRODUCT HANDBOOK
INDEX](#)
[PART NUMBER CROSS
REFERENCE](#)


[Technical Reference Selection Guide](#)

Strain Gage Technical Data

Strain Gage Measurement

The most universal measuring device for the electrical measurement of mechanical quantities is the strain gage. Several types of strain gages depend on the proportional variance of electrical resistance to strain: the piezoresistive or semi-conductor gage, the carbon-resistive gage, the bonded metallic wire, and foil resistance gages.

The bonded resistance strain gage is by far the most widely used in experimental stress analysis. These gages consist of a grid of very fine wire or foil bonded to the backing or carrier matrix. The electrical resistance of the grid varies linearly with strain. In use, the carrier matrix is bonded to the surface, force is applied, and the strain is found by measuring the change in resistance. The bonded resistance strain gage is low in cost, can be made with a short gage length, is only moderately affected by temperature changes, has small physical size and low mass, and has fairly high sensitivity to strain.



In a strain gage application, the carrier matrix and the adhesive must work together to transmit the strains from the specimen to the grid. In addition, they serve as an electrical insulator and heat dissipator.

The three primary factors influencing gage selection are operating temperature, state of strain (gradient, magnitude, and time dependence) and stability required.

Because of its outstanding sensitivity, the Wheatstone bridge circuit is the most frequently used circuit for static strain measurements. Ideally, the strain gage is the only resistor in the circuit that varies and then only due to a change in strain on the surface.

There are two main methods used to indicate the change in resistance caused by strain on a gage in a Wheatstone bridge. Often, an indicator will rebalance the bridge, displaying the change in resistance required in micro-strain. The second method installs an indicator, calibrated in micro-strain, that responds to the voltage output of the bridge. This method assumes a linear relationship between voltage out and strain, an initially balanced bridge, and known V in. In reality, the V out-strain relationship is nonlinear, but for strains up to a few thousand micro-strain, the error is not significant.

Potential Error Sources

In a stress analysis application, the entire gage installation cannot be calibrated as can some pressure transducers. Therefore, it is important to examine potential error sources prior to taking data.

Some gages may be damaged during installation. It is important therefore to check the resistance of the strain gage prior to stress.

Electrical noise and interference may alter your readings. Shielded leads and adequately insulating coatings may prevent these problems. A value of less than 500 M ohms (using an ohmmeter) usually indicates surface contamination.

Thermally induced voltages are caused by thermocouple effects at the junction of dissimilar metals within the measurement circuit. Magnetically induced voltages may occur when the wiring is located in a time varying magnetic field. Magnetic induction can be controlled by using twisted lead wires and forming minimum but equal loop areas in each side of the bridge.

Temperature effects on gage resistance and gage factor should be compensated for as well. This may require measurement of temperature at the gage itself, using thermocouples, thermistors, or RTDs. Most metallic gage alloys, however, exhibit a nearly linear gage factor variation with temperature over a broad range which is less than $\pm 1\%$ within $\pm 100^\circ\text{C}$.

Prime Strain Gage Selection Considerations

- Gage Length
- Number of Gages in Gage Pattern
- Arrangement of Gages in Gage Pattern
- Grid Resistance
- Strain Sensitive Alloy
- Carrier Material
- Gage Width
- Solder Tab Type
- Configuration of Solder Tab
- Availability

Strain gage dimensions

The active grid length, in the case of foil gages, is the net grid length without the tabs and comprises the return loops of the wire gages. The carrier, dimensions are designed by OMEGA for the optimum function of the strain gage.

Strain gage resistance

The resistance of a strain gage is defined as the electrical resistance measured between the two metal ribbons or contact areas intended for the connection of measurement cables. The range comprises strain gages with a nominal resistance of 120, 350, 600, and 700 Ohms.

Gage Factor (Strain Sensitivity)

The strain sensitivity k of a strain gage is the proportionality factor between the relative change of the resistance.

The strain sensitivity is a figure without dimension and is generally called gage factor.

The gage factor of each production lot is determined by sample measurements and is given on each package as the nominal value with its tolerance. Reference Temperature The reference temperature is the ambient temperature for which the technical data of the strain gages are valid, unless temperature ranges are given. The technical data quoted for strain gages are based on a reference temperature of 23°C .

Temperature Characteristic

Temperature dependent changes of the specific strain gage grid resistance occur in the applied gage owing to the linear thermal expansion coefficients of the grid and specimen materials. These resistance changes appear to be mechanical strain in the specimen. The representation of the apparent strain as a function of temperature is called the temperature characteristic of the strain gage application. In order to keep apparent strain through temperature changes as small as possible, each strain gage is matched during the production to a certain linear thermal expansion coefficient. OMEGA offers strain gages with temperature characteristics matched to ferritic steel and aluminum.

Service Temperature Range

The service temperature range is the range of ambient temperature where the use of the strain gages is permitted without permanent changes of the measurement properties. Service temperature ranges are different whether static or dynamic values are to be sensed.

Maximum Permitted RMS Bridge Energizing Voltage

The maximum values quoted are only permitted for appropriate application on materials with good heat conduction (e.g., steel of sufficient thickness) if room temperature is not exceeded. In other cases temperature rise in the measuring grid

area may lead to measurement errors. Measurements on plastics and other materials with bad heat conduction require the reduction of the energizing voltage or the duty cycle (pulsed operation).

THE STRAIN GAGE IS ONE OF THE MOST IMPORTANT TOOLS of the electrical measurement technique applied to the measurement of mechanical quantities. As their name indicates, they are used for the measurement of strain. As a technical term "strain" consists of tensile and compressive strain, distinguished by a positive or negative sign. Thus, strain gages can be used to pick up expansion as well as contraction. The strain of a body is always caused by an external influence or an internal effect. Strain might be caused by forces, pressures, moments, heat, structural changes of the material and the like. If certain conditions are fulfilled, the amount or the value of the influencing quantity can be derived from the measured strain value. In experimental stress analysis this feature is widely used. Experimental stress analysis uses the strain values measured on the surface of a specimen or structural part to state the stress in the material and also to predict its safety and endurance. Special transducers can be designed for the measurement of forces or other derived quantities, e.g., moments, pressures, accelerations, and displacements, vibrations and others. The transducer generally contains a pressure sensitive diaphragm with strain gages bonded to it.



© Copyright 2003-2007 | OMEGA ENGINEERING, Inc. | OMEGA Privacy
Statement | Terms and Conditions

MXV MMV |
71




POSITIONING STRAIN GAGES TO MONITOR BENDING, AXIAL, SHEAR, AND TORSIONAL LOADS

In the glossary to the Pressure Reference Section, "strain" is defined as the ratio of the change in length to the initial unstressed reference length. A strain gage is the element that senses this change and converts it into an electrical signal. This can be accomplished because a strain gage changes resistance as it is stretched, or compressed, similar to wire. For example, when wire is stretched, its cross-sectional area decreases; therefore, its resistance increases.


The important factors that must be considered before selecting a strain gage are the direction, type, and resolution of the strain you wish to measure.

To measure minute strains, the user must be able to measure minute resistance changes. The Wheatstone Bridge configuration, shown in Figure B, is capable of measuring these small resistance changes. Note the signs associated with each gage numbered 1 through 4. The total strain is always the sum of the four strains.



The total strain is represented by a change in V_{OUT} . If each gage had the same positive strain, the total would be zero and V_{OUT} would remain unchanged. Bending, axial, and shear strain are the most common types of strain measured. The actual arrangement of your strain gages will determine the type of strain you can measure and the output voltage change. See Figures C through F.

For example, if a positive (tensile) strain is applied to gages 1 and 3, and a negative (compressive) strain to gages 2 and 4, the total strain



would be 4 times the strain on one gage. See Figure C.

If total strain is four times the strain on one gage, this means that the output will be four times larger. Therefore, greater sensitivity and resolution are possible when more than one strain gage is used.

The following equations show the relationships

among stress, strain, and force for bending, axial, shear, and torsional strain.

- BENDING STRAIN** or moment strain is equal to bending stress divided by Young's Modulus of Elasticity.

$$\epsilon_B = \sigma_B / E \quad \sigma_B = M_B / Z = F_V(\cdot) / Z$$

Moment stress (σ_B) equals bending moment ($F_V \times \cdot$) divided by sectional modulus. Sectional modulus (Z) is a property of the cross-sectional configuration of the specimen. For rectangles only, the

sectional modulus is $(bh^2/6)$. Strain gages used in the bending strain configuration can be used to determine vertical load (F_V); this is more commonly referred to as a bending beam load cell.

$$F_V = E \epsilon_B(Z) // = E \epsilon_B(bh^2/6) //$$

- AXIAL STRAIN** equals axial stress divided by Young's Modulus.

$$E_A = \sigma_A / E \quad \sigma_A = F_A / A$$

Where axial stress (σ_A) equals the axial load divided by the cross-sectional area. The cross-sectional area for rectangles equals $(b \times d)$. Therefore, strain gages used in axial configurations can be used to determine axial loads (F (axial)).

$$F \text{ (axial)} = E \epsilon_A bh$$

- SHEAR STRAIN** equals shear stress divided by modulus of shear stress.

$$\gamma = \tau / G \quad \tau = F_V \times Q / bl$$

Where shear stress (τ) equals (Q), the moment of area about the neutral axis multiplied by the vertical load (F_V) divided by the thickness (b) and the moment of

POSITIONING STRAIN GAGES TO MONITOR BENDING, AXIAL, SHEAR, AND TORSIONAL LOADS

inertia (I). Both the moment of area (Q) and the moment of inertia (I) are functions of the specimen's cross-sectional geometry.

For rectangles only
 $Q = bh^2/6$ and $I = bh^3/12$

The shear strain (γ) is determined by measuring the strain at a 45° angle, as shown in Figure E.

$$\gamma = 2 \times \epsilon @ 45^\circ$$

The modulus of shear strain (G) = E/2 (1 + μ). Therefore, strain gages used in a shear strain configuration can be used to determine vertical loads (F_V); this is more commonly referred to as a shear beam load cell.

$$\begin{aligned} F_V &= G (\gamma) bI/Q \\ &= G (\gamma) b (bh^2/12)/(bh^2/6) \\ &= G (\gamma)bh(2/3) \end{aligned}$$

- 4) **TORSIONAL STRAIN** equals torsional stress (τ) divided by torsional modulus of elasticity (G). See Figure F.

$$\begin{aligned} \gamma &= 2 \times \epsilon @ 45^\circ = \tau/G \\ \tau &= M_t(d/2)/J \end{aligned}$$

where torsional stress (τ) equals torque (M_t) multiplied by the distance from the center of the section to the outer fiber (d/2), divided by (J), the polar moment of inertia. The polar moment of inertia is a function of the cross-sectional area. For solid circular shafts only, $J = \pi(d)^4/32$. The modulus of shear strain (G) has been defined in the preceding discussion on shear stress. Strain gages can be used to determine torsional moments as shown in the equation below. This represents the principle behind every torque sensor.

$$\begin{aligned} M_t &= \tau(J) (2/d) \\ &= \gamma G (J) (2/d) \\ &= \gamma G (\pi d^3/6) \\ \emptyset &= M_t L/G(J) \end{aligned}$$

a gage factor of 2.0, Poisson's Ratio of 0.3, and it disregards the lead wire resistance.


This chart is quite useful in determining the meter sensitivity required to read strain values.

Temperature compensation is achieved in many of the above configurations. Temperature compensation means that the gage's thermal expansion coefficient does not have to match the specimen's thermal expansion coefficient; therefore, any OMEGA® strain gage, regardless of its temperature characteristics, can be used with any specimen material. Quarter bridges can have temperature compensation if a dummy gage is used. A dummy gage is a strain gage used in place of a fixed resistor. Temperature compensation is achieved when this dummy gage is mounted on a piece of material similar to the specimen which undergoes the same temperature changes as does the specimen, but which is not exposed to the same strain. Strain temperature compensation is not the same as load (stress) temperature compensation, because Young's Modulus of Elasticity varies with temperature.

The following table shows how bridge configuration affects output, temperature compensation, and compensation of superimposed strains. This table was created using

STRAIN	BRIDGE TYPE	POSITION OF GAGES FIG. C-F	SENSITIVITY mV/V @ 1000 $\mu\epsilon$	OUTPUT PER $\mu\epsilon$ @ 10 V EXCITATION	TEMP. COMP.	SUPERIMPOSED STRAIN COMPENSATED
BENDING	1/4	1	0.5	5 $\mu V/\mu\epsilon$	No	None
	1/2	1, 2	1.0	10 $\mu V/\mu\epsilon$	Yes	Axial
	Full	All	2.0	20 $\mu V/\mu\epsilon$	Yes	Axial
AXIAL	1/4	1	0.5	5 $\mu V/\mu\epsilon$	No	None
	1/2	1, 2	0.65	6.5 $\mu V/\mu\epsilon$	Yes	None
	1/2	1, 3	1.0	10 $\mu V/\mu\epsilon$	No	Bending
	Full	All	1.3	13 $\mu V/\mu\epsilon$	Yes	Bending
SHEAR AND TORSIONAL	1/2	1, 2	1.0	10 $\mu V/\mu\epsilon$ @ 45°F	Yes	Axial and Bending
	Full	All	2.0	20 $\mu V/\mu\epsilon$ @ 45°F	Yes	Axial and Bending

Note: Shear and torsional strain = 2 x ϵ @ 45°.



User's Guide



www.omega.com
[e-mail:info@omega.com](mailto:info@omega.com)



DMD-465 Bridgesensor AC Powered Signal Conditioner

Features

- Rugged, Compact and Fully Encapsulated
- Complete System - Just Add AC Power
- Ready to Use with Screwdriver Wiring
- Stable and Accurate

Applications

- Weighing with Load Cells
- Long Term Structural Monitoring
- Process Control Pressure Transducers
- Low Frequency Strain Measurements

Transducer Excitation

Transducer bridge excitation is provided by an AC line powered, adjustable, well regulated, low noise power supply. The excitation voltage is adjusted by means of a molded-in potentiometer, which allows the output voltage to be varied from 4 to 15 Volts. The output ripple is extremely low and the line and load regulation are 0.05%.

The sense lines minimize variations in output voltage with changes in load current or lead resistance. It should be noted that if the sense feature is not being used, terminal 1 must be connected to terminal 2. Terminals 3 and 4 must be connected also. The supply will provide up to 150mA of output current. These features make the unit ideal for use with most common strain gage bridge circuits of 120, 350, and 500 Ohms.

The supply has short circuit protection to protect it against short term faults. The output recovers automatically from short circuit conditions once the short is removed.




FIGURE 1. Bridge Supply - Safe Operation

Description

The Model 465 is a self contained, AC powered, signal conditioning module for bridge type instrumentation. It contains a precision differential instrumentation amplifier with filtered output and a highly regulated, low noise, adjustable output bridge excitation source. The unit is completely encapsulated for use in rugged environments.

Safe Operation in the Unsafe Area

The curve (Figure 1) describes the region of safe operating output current at each voltage setting level. If excitation is desired at the 4 Volt level with 150mA, this can be accomplished by using a resistor of at least 2 Watts in size in series with the bridge. The right value resistor would drop 11 Volts allowing 4 Volts at 150mA across the bridge while minimizing internal heating of the Model 465. The + sense line would regulate the supply to the required 4 Volts. Normal operation of single bridges at 10 Volts and under 100mA (all 120, 350, and 500 Ohm bridges) can be accomplished within the safe operating area.

Instrumentation Amplifier

The built-in amplifier is a true differential input, low noise, low drift, instrumentation amplifier. It has a high common mode rejection ratio (CMRR) and is provided with an output offset that is potentiometer adjustable. The minimum gain setting of the amplifier is 40 and the maximum gain using the built-in potentiometer is 250. The gain may be adjusted up to a maximum of 1,000 by means of an external resistor connected across terminals 12 and 13. The size of the external resistor can be calculated using the gain formula in the specifications. When doing this the coarse gain potentiometer should be turned fully clockwise. The fine gain pot can then be used for final gain adjustment. The output offset adjustment range is $\pm 0.5V$.

The amplifier can withstand input voltages up to 15 Volts without damage. The output of the amplifier is filtered to be 3 dB down at 3 Hz using a double pole Butterworth response filter to minimize the effects of high frequency electrical and physical noise on the system. The output of the amplifier is ± 10 Volts at 5mA making it compatible with modern data acquisition techniques and systems.

Specifications

(Typical @ 25°C unless noted)

Amplifier	
Gain Range with external R	40 - 250 to 1,000
Gain Temperature Coefficient	200 ppm/°C
Gain Potentiometer Hysteresis	0.2% of span max.
Gain Equation <i>Note: G is the desired voltage gain in V/V</i>	$R_g = \frac{G - 1}{40 \text{ k}\Omega} - \frac{1}{150\Omega}$
Drift (RTI)	2 ±20/G μV/°C
Input Bias Current	±30 nA
Input Impedance	
Differential	3,000 megohms
Common Mode	6 megohms
Output Noise (RTO) at gain = 100 1 Hz to 100 Hz	120 μV RMS
Common Mode Rejection	
Gain = 40 (DC)	96 dB
Rated Output (2k load)	±10V
Common Mode Voltage	±6.5V
Output Impedance (DC)	0.01 ohms
Dynamic Response	0.3s to 0.1%
DC to -3 dB two pole Butterworth Filter	3 Hz
Max. Input Voltage	±15V
Bridge Supply	
Input	115 VAC ±10% 50 to 60 Hz (100, 220 & 230 VAC available)
Output Voltage	4 to 15 Volts
Output Current	5 to 150 mA
(see output voltage vs current curve)	
Load & Line Regulation 0.05% V _{OUT} = 12V, I _L = 5 to 100 mA	
Output Noise	0.5 mV RMS
Drift	200 ppm/°C max.
B+ Potentiometer Hysteresis	0.3% of output max.
Short Circuit Current	750 mA
Line Isolation	1,500 VDC
Mechanical	
Operating Temperature	0°C to 70°C
Storage Temperature	-25°C to +85°C
Weight	18 oz. (510 grams)
Size	3.75"L x 2.0"W x 2.87"H 9.53 x 5.1 x 7.62 (cm)

Getting Started with the Model 465

I. Hook Up Procedure

- A. Connect the +out of your load cell to the +INPUT, pin 10.
- B. Connect the -out of your load cell to the -INPUT, pin 11.

Note: If the ±SENSE are not used in your load cell application, the connections in step C & D need to be followed. If the ±SENSE are going to be used, do not jumper them as described in steps C & D.

- C. Connect B+, pin 4, to the +excitation of your load cell and jumper the +SENSE, pin 3, to B+, pin 4.
- D. Connect B-, pin 2, to the -excitation of your load cell and jumper the -SENSE, pin 1, to B-, pin 2.
- E. Connect the VAC power supply to the AC input lines, pins 6 and 7.

II. Turn On Procedure

- A. Verify that the hook up procedure is complete.
- B. Verify the correct AC voltage is applied to the 465; i.e. 100, 115, 220, 230.
- C. Turn on the AC source supply to the 465.
- D. Set the required EXCITATION supply voltage to the load cell by adjusting B+ ADJUST, Pot B

III. Calibration Procedure for Zero Adjustment

- A. Jumper the + and - input terminals, pins 10 and 11, together.
- B. Connect a volt meter across the output, pins 8 and 9.
- C. Adjust the OUTPUT OFFSET, Pot A, potentiometer for zero.

IV. Full Scale Voltage Adjustment

- A. Remove the jumper between the + and - input terminals and apply a known load to your load cell, in most cases it would be 100% of full scale.
- B. Adjust the COARSE GAIN, Pot D, and FINE GAIN, Pot C, potentiometers for the desired FULL SCALE output.
- C. Calibration is now complete. However, the user should recheck the ZERO & FULL SCALE output before continuing.

Typical Bridge Application

Figure 2 shows a typical load cell application using a standard 350 Ohm bridge. Typical bridge output is 2 or 3mV/Volt of excitation. With the power supply excitation voltage at 10 Volts an output of 20 or 30mV from the bridge can be obtained. The common mode voltage of the bridge (the instrumentation amplifier input signal level) is 5 Volts. This is well within the 6.5 Volt common mode voltage range of the amplifier.




FIGURE 2. Typical load Cell Application

The gain must be set between 300 and 600 depending on the output of the bridge. The built-in potentiometer set to a gain of 200 would achieve an output voltage of 4 to 6 Volts. For a higher level output an external resistor must be used. The value of that resistor can be calculated using the gain formula. It can also be arrived at empirically using a calibrated input signal equal to the maximum input signal expected and a resistance substitution box to adjust the gain until the desired full scale output voltage is achieved.

Assuming a standard 350 Ohm bridge is used, the current required from the excitation supply (set at 10 Volts) would be 28.6mA. If the leads were long enough to have 10 Ohms of internal resistance there would be a drop of over 0.25 Volts in both the plus and common side of the bridge. To eliminate this potential error (especially where the current might vary during the course of a measurement) the sense lines are connected to measure and regulate the voltage right at the bridge rather than at the output of the supply thereby eliminating this potential source of error. The decision of whether to use the sense leads or not depends entirely on the lead length, its resistance and the effect of that error on the measurement.

Application Suggestions

The Model 465 is designed to eliminate many of the ordinary problems associated with bridge type measurements. Since the whole system is in one case the common problem of ground loops or circulating currents caused by poor wiring practices is eliminated. It is recommended that lead lengths be kept to a minimum. The use of shielded twisted pairs for the input leads is recommended for most applications.

To minimize self heating errors the use of minimum excitation power is suggested as is sufficient heatsinking of the transducer wherever possible. For optimum stability a one hour warm-up is recommended. Avoid large temperature changes or stray magnetic fields.

The output leads should be kept short to minimize capacitive loading on the output of the amplifier. The Model 465 Bridgesensor is ready to wire into your system, have power applied, and to start making measurements for you.

Mechanical Specifications

Specifically designed for rugged field use the Model 465 is completely encapsulated in epoxy using a vacuum potting system to insure a complete seal against corrosive environments. It is similarly protected against shock and vibration and will provide years of reliable and accurate operation.









FIGURE 3

Terminal Strip Assignments			
Screw Terminal	Function	Screw Terminal	Function
1	-SENSE	8	OUTPUT
2	B-	9	AMPLIFIER CMN
3	+SENSE	10	+INPUT
4	B+	11	-INPUT
5	NOT USED	12	EXT. GAIN
6	AC	13	EXT. GAIN
7	AC		

Practical Temperature Measurements

Application Note 290



Agilent Technologies

Innovating the HP Way

Contents

Introduction	2
The Thermocouple	4
Practical Thermocouple Measurements	11
The RTD	18
The Thermistor	22
Monolithic Linear Temperature Sensor	23
The Measurement System	24
Appendix A	27
Appendix B	28
Thermocouple Hardware	30
Bibliography	31

Introduction

The purpose of this application note is to explore the more common temperature measurement techniques, and introduce procedures for improving their accuracy.

We will focus on the four most common temperature transducers: the thermocouple, the RTD (Resistance Temperature Detector), the thermistor and the integrated circuit sensor.

Despite the widespread popularity of the thermocouple, it is frequently misused. For this reason, we will concentrate primarily on thermocouple measurement techniques.

Appendix A contains the empirical laws of thermocouples which are the basis for all derivations used herein. Readers wishing a more thorough discussion of thermocouple theory are invited to read reference 3 in the Bibliography.

For those with a specific thermocouple application, Appendix B may aid in choosing the best type of thermocouple.

Throughout this application note we will emphasize the practical considerations of transducer placement, signal conditioning and instrumentation.

Early Measuring Devices

Galileo is credited with inventing the thermometer, circa 1592.^{1,2} In an open container filled with colored alcohol, he suspended a long narrow-throated glass tube, at the upper end of which was a hollow sphere. When heated, the air in the sphere expanded and bubbled through the liquid. Cooling the sphere caused the liquid to move up the tube.¹ Fluctuations in the temperature of the sphere could then be observed by noting the position of

the liquid inside the tube. This “upside-down” thermometer was a poor indicator since the level changed with barometric pressure, and the tube had no scale. Vast improvements were made in temperature measurement accuracy with the development of the Florentine thermometer, which incorporated sealed construction and a graduated scale.

In the ensuing decades, many thermometric scales were conceived, all based on two or more fixed points. One scale, however, wasn’t universally recognized until the early 1700’s when Gabriel Fahrenheit, a Dutch instrument maker, produced accurate and repeatable mercury thermometers. For the fixed point on the low end of his temperature scale, Fahrenheit used a mixture of ice water and salt (or ammonium chloride). This was the lowest temperature he could reproduce, and he labeled it “zero degrees.” For the high end of his scale, he chose human blood temperature and called it 96 degrees.

Why 96 and not 100 degrees? Earlier scales had been divided into twelve parts. Fahrenheit, in an apparent quest for more resolution divided his scale into 24, then 48 and eventually 96 parts.

The Fahrenheit scale gained popularity primarily because of the repeatability and quality of the thermometers that Fahrenheit built.

Around 1742, Anders Celsius proposed that the melting point of ice and the boiling point of water be used for the two benchmarks. Celsius selected zero degrees as the boiling point and 100 degrees as the melting point. Later, the end points were reversed and the centigrade scale was born. In 1948 the name was officially changed to the Celsius scale.

In the early 1800's William Thomson (Lord Kelvin), developed a universal thermodynamic scale based upon the coefficient of expansion of an ideal gas. Kelvin established the concept of absolute zero, and his scale remains the standard for modern thermometry.

The conversion equations for the four modern temperature scales are:

$$\begin{aligned} ^\circ\text{C} &= 5/9 (^{\circ}\text{F} - 32) & ^\circ\text{F} &= 9/5 ^\circ\text{C} + 32 \\ k &= ^\circ\text{C} + 273.15 & ^\circ\text{R} &= ^\circ\text{F} + 459.67 \end{aligned}$$

The Rankine Scale ($^{\circ}\text{R}$) is simply the Fahrenheit equivalent of the Kelvin scale, and was named after an early pioneer in the field of thermodynamics, W. J. M. Rankine. Notice the official Kelvin scale does not carry a degree sign. The units are expressed in "kelvins," not degrees Kelvin.

Reference Temperatures

We cannot build a temperature divider as we can a voltage divider, nor can we add temperatures as we would add lengths to measure distance. We must rely upon temperatures established by physical phenomena which are easily observed and consistent in nature.

The International Temperature Scale (ITS) is based on such phenomena. Revised in 1990, it establishes seventeen fixed points and corresponding temperatures. A sampling is given in Table 1.

Since we have only these fixed temperatures to use as a reference, we must use instruments to interpolate between them. But accurately interpolating between these temperatures can require some fairly exotic transducers, many of which are too complicated or expensive to use in a practical situation. We shall limit our discussion to the four most common temperature transducers: thermocouples, resistance-temperature detector's (RTD's), thermistors, and integrated circuit sensors.





Thermocouple	RTD	Thermistor	I. C. Sensor
			
Advantages <ul style="list-style-type: none"> • Self-powered • Simple • Rugged • Inexpensive • Wide variety of physical forms • Wide temperature range 	<ul style="list-style-type: none"> • Most stable • Most accurate • More linear than thermocouple 	<ul style="list-style-type: none"> • High output • Fast • Two-wire ohms measurement 	<ul style="list-style-type: none"> • Most linear • Highest output • Inexpensive
Disadvantages <ul style="list-style-type: none"> • Non-linear • Low voltage • Reference required • Least stable • Least sensitive 	<ul style="list-style-type: none"> • Expensive • Slow • Current source required • Small resistance change • Four-wire measurement 	<ul style="list-style-type: none"> • Non-linear • Limited temperature range • Fragile • Current source required • Self-heating 	<ul style="list-style-type: none"> • $T < 250^{\circ}\text{C}$ • Power supply required • Slow • Self-heating • Limited configurations

Table 1
ITS-90 Fixed Points

Element	Type	Temperature K	$^{\circ}\text{C}$
(H ₂) Hydrogen	Triple Point	13.8033 K	-259.3467 $^{\circ}\text{C}$
(Ne) Neon	Triple Point	24.5561 K	-248.5939 $^{\circ}\text{C}$
(O ₂) Oxygen	Triple Point	54.3584 K	-218.7916 $^{\circ}\text{C}$
(Ar) Argon	Triple Point	83.8058 K	-189.3442 $^{\circ}\text{C}$
(Hg) Mercury	Triple Point	234.315 K	-38.8344 $^{\circ}\text{C}$
(H ₂ O) Water	Triple Point	273.16 K	+0.01 $^{\circ}\text{C}$
(Ga) Gallium	Melting Point	302.9146 K	29.7646 $^{\circ}\text{C}$
(In) Indium	Freezing Point	429.7485 K	156.5985 $^{\circ}\text{C}$
(Sn) Tin	Freezing Point	505.078 K	231.928 $^{\circ}\text{C}$
(Zn) Zinc	Freezing Point	692.677 K	419.527 $^{\circ}\text{C}$
(Al) Aluminum	Freezing Point	933.473 K	660.323 $^{\circ}\text{C}$
(Ag) Silver	Freezing Point	1234.93 K	961.78 $^{\circ}\text{C}$
(Au) Gold	Freezing Point	1337.33 K	1064.18 $^{\circ}\text{C}$

The Thermocouple

When two wires composed of dissimilar metals are joined at both ends and one of the ends is heated, there is a continuous current which flows in the *thermoelectric* circuit. Thomas Seebeck made this discovery in 1821 (Figure 2).

If this circuit is broken at the center, the net open circuit voltage (the Seebeck voltage) is a function of the junction temperature and the composition of the two metals (Figure 3).

All dissimilar metals exhibit this effect. The most common combinations of two metals are listed on page 28 of this application note, along with their important characteristics. For small changes in temperature the Seebeck voltage is linearly proportional to temperature:
 $e_{AB} = \alpha T$

Where α , the Seebeck coefficient, is the constant of proportionality. (For real world thermocouples, α is not constant but varies with temperature. This factor is discussed under "Voltage-to-Temperature Conversion" on page 9.)

Measuring Thermocouple Voltage

We can't measure the Seebeck voltage directly because we must first connect a voltmeter to the thermocouple, and the voltmeter leads, themselves, create a new thermoelectric circuit.

Let's connect a voltmeter across a copper-constantan (Type T) thermocouple and look at the voltage output (Figure 4).

We would like the voltmeter to read only V_1 , but by connecting the voltmeter in an attempt to measure the output of Junction J_1 we have created two more metallic junctions: J_2 and J_3 . Since J_3 is a copper-copper junction, it creates no thermal e.m.f. ($V_3 = 0$) but J_2 is a copper-to-constantan junction which will add an e.m.f. (V_2) in opposition to V_1 . The resultant voltmeter reading V will be proportional to the temperature *difference* between J_1 and J_2 . This says that we can't find the temperature at J_1 unless we first find the temperature of J_2 .

The Reference Junction

One way to determine the temperature J_2 is to physically put the junction into an ice bath, forcing its temperature to be 0°C and establishing J_2 as the *Reference Junction*. Since both voltmeter terminal junctions are now copper-copper, they create no thermal e.m.f. and the reading V on the voltmeter is proportional to the temperature difference between J_1 and J_2 .

Now the voltmeter reading is (See Figure 5):

$$V = (V_1 - V_2) \cong \alpha(t_{J_1} - t_{J_2})$$

If we specify T_{J_1} in degrees Celsius:

$$T_{J_1} (^{\circ}\text{C}) + 273.15 = t_{J_1} (\text{K})$$

then V becomes:

$$V = V_1 - V_2 = \alpha[(T_{J_1} + 273.15) - (T_{J_2} + 273.15)] \\ = \alpha(T_{J_1} - T_{J_2}) = (T_{J_1} - 0)$$

$$V = \alpha T_{J_1}$$

Figure 2
The Seebeck Effect




Figure 3





Figure 4
Measuring junction voltage with a DVM



We use this protracted derivation to emphasize that the ice bath junction output V_2 is not zero volts. It is a function of absolute temperature.

By adding the voltage of the ice point reference junction, we have now referenced the reading V to 0°C . This method is very accurate because the ice point temperature can be precisely controlled. The ice point is used by the National Institute of Standards and Technology (NIST) as the fundamental reference point for their thermocouple tables, so we can now look at the NIST tables and directly convert from voltage V to Temperature T_{J_1} .

The copper-constantan thermocouple shown in Figure 5 is a unique example because the copper wire is the same metal as the voltmeter terminals. Let's use an iron-constantan (Type J) thermocouple instead of the copper-constantan. The iron wire (Figure 6) increases the number of dissimilar metal junctions in the circuit, as both voltmeter terminals become Cu-Fe thermocouple junctions.

This circuit will still provide moderately accurate measurements as long as the voltmeter *high* and *low* terminals (J_3 & J_4) act in opposition (Figure 7).

If both front panel terminals are not at the same temperature, there will be an error. For a more precise measurement, the copper voltmeter leads should be extended so the copper-to-iron junctions are made on an isothermal (same temperature) block (Figure 8).

The isothermal block is an electrical insulator but a good heat conductor and it serves to hold J_3 and J_4 at the same temperature. The absolute block temperature is unimportant because the two Cu-Fe junctions act in opposition. We still have:

$$V = \alpha(T_{J_1} - T_{REF})$$

Figure 5
External reference junction




Figure 6
Iron Constantan couple




Figure 7
Junction voltage cancellation





Figure 8
Removing junctions from DVM terminals



Reference Circuit

The circuit in Figure 8 will give us accurate readings, but it would be nice to eliminate the ice bath if possible.

Let's replace the ice bath with another isothermal block (Figure 9).

The new block is at Reference Temperature T_{REF} , and because J_3 and J_4 are still at the same temperature we can again show that:
 $V = \alpha(T_1 - T_{REF})$

This is still a rather inconvenient circuit because we have to connect two thermocouples. Let's eliminate the extra Fe wire in the negative (LO) lead by combining the Cu-Fe junction (J_4) and the Fe-C junction (J_{REF}).

We can do this by first joining the two isothermal blocks (Figure 9b).

We haven't changed the output voltage V . It is still:
 $V = \alpha(T_{J_1} - T_{REF})$

Now we call upon the law of intermediate metals (see Appendix A) to eliminate the extra junction. This empirical law states that a third metal (in this case, iron) inserted between the two dissimilar metals of a thermocouple junction will have no effect upon the output voltage as long as the two junctions formed by the additional metal are at the same temperature (Figure 10).

This is a useful conclusion, as it completely eliminates the need for the iron (Fe) wire in the LO lead (Figure 11).

Again $V = \alpha(T_1 - T_{REF})$ where α is the Seebeck coefficient for an Fe-C thermocouple.

Junctions J_3 and J_4 take the place of the ice bath. These two junctions now become the *reference junction*.

Figure 9a
Eliminating the ice bath




Figure 9b
Joining the isothermal blocks






Figure 10
Law of intermediate metals



Thus the low lead in Fig. 9b:



Becomes:





Figure 11
Equivalent circuit



Now we can proceed to the next logical step: Directly measure the temperature of the isothermal block (the reference junction) and use that information to compute the unknown temperature, T_{J_1} (Figure 12).

A thermistor, whose resistance R_T is a function of temperature, provides us with a way to measure the absolute temperature of the reference junction. Junctions J_3 and J_4 and the thermistor are all assumed to be at the same temperature, due to the design of the isothermal block. Using a digital multimeter (DMM), we simply:

1. Measure R_T to find T_{REF} and convert T_{REF} to its equivalent reference junction voltage, V_{REF}
2. Measure V and add V_{REF} to find V_1 and convert V_1 to temperature T_{J_1} .

This procedure is known as *software compensation* because it relies upon software in the instrument or a computer to compensate for the effect of the reference junction. The isothermal terminal block temperature sensor can be any device which has a characteristic proportional to absolute temperature: an RTD, a thermistor, or an integrated circuit sensor.

It seems logical to ask: If we already have a device that will measure absolute temperature (like an RTD or thermistor), why do we even bother with a thermocouple that requires reference junction compensation? The single most important answer to this question is that the thermistor, the RTD, and the integrated circuit transducer are only useful over a certain temperature range. Thermocouples, on the other hand, can be used over a range of temperatures, and optimized for various atmospheres. They are much more rugged than thermistors, as evidenced by the fact that thermocouples are often welded to a metal part or clamped under a screw. They can be manufactured on the spot, either by soldering or welding. In short, thermocouples are the most versatile temperature transducers available and since the measurement system performs the entire task of

Figure 12
External reference junction - no ice bath





Figure 13
Switching multiple thermocouple types



reference compensation and software voltage-to-temperature conversion, using a thermocouple becomes as easy as connecting a pair of wires.

Thermocouple measurement becomes especially convenient when we are required to monitor a large number of data points. This is accomplished by using the isothermal reference junction for more than one thermocouple element (Figure 13). A relay scanner connects the voltmeter to the various thermocouples in sequence. All of the voltmeter and scanner wires are copper, independent of the type of thermocouple chosen. In fact, as long as we know what each thermocouple is, we can mix thermocouple types on the same isothermal junction block (often called a *zone box*) and make the appropriate modifications in software. The junction block temperature sensor, R_T is located at the center of the block to minimize errors due to thermal gradients.

Software compensation is the most versatile technique we have for measuring thermocouples. Many thermocouples are connected on the same block, copper leads are used throughout the scanner, and the technique is independent of the types of thermocouples chosen. In addition, when using a data acquisition system with a built-in zone box, we simply connect the thermocouple as we would a pair of test leads. All of the conversions are performed by the instrument's software. The one disadvantage is that it requires a small amount of additional time to calculate the reference junction temperature. For maximum speed we can use hardware compensation.

Hardware Compensation

Rather than measuring the temperature of the reference junction and computing its equivalent voltage as we did with software compensation, we could insert a battery to cancel the offset voltage of the reference junction. The combination of this hardware compensation voltage and the reference junction voltage is equal to that of a 0° C junction (Figure 14).

The compensation voltage, e , is a function of the temperature sensing resistor, R_T . The voltage V is now referenced to 0° C, and may be read directly and converted to temperature by using the NIST tables.

Another name for this circuit is the *electronic ice point reference*.⁶ These circuits are commercially available for use with any voltmeter and with

a wide variety of thermocouples. The major drawback is that a unique ice point reference circuit is usually needed for each individual thermocouple type.

Figure 15 shows a practical ice point reference circuit that can be used in conjunction with a relay scanner to compensate an entire block of thermocouple inputs. All the thermocouples in the block must be of the same type, but each block of inputs can accommodate a different thermocouple type by simply changing gain resistors.

The advantage of the hardware compensation circuit or electronic ice point reference is that we eliminate the need to compute the reference temperature. This saves us two computation steps and makes a hardware compensation temperature measurement somewhat faster than a software

compensation measurement. However, today's faster microprocessors and advanced data acquisition designs continue to blur the line between the two methods, with software compensation speeds challenging those of hardware compensation in practical applications (Table 2).

Table 2

Hardware Compensation	Software Compensation
<ul style="list-style-type: none"> • Fast 	<ul style="list-style-type: none"> • Requires more software manipulation time
<ul style="list-style-type: none"> • Restricted to one thermocouple type per reference junction 	<ul style="list-style-type: none"> • Versatile – accepts any thermocouple
<ul style="list-style-type: none"> • Hard to reconfigure – requires hardware change for new thermocouple type 	<ul style="list-style-type: none"> • Easy to reconfigure

Figure 14
Hardware compensation circuit





Figure 15
Practical hardware compensation



Voltage-To-Temperature Conversion

We have used hardware and software compensation to synthesize an ice-point reference. Now all we have to do is to read the digital voltmeter and convert the voltage reading to a temperature. Unfortunately, the temperature-versus-voltage relationship of a thermocouple is not linear. Output voltages for some popular thermocouples are plotted as a function of temperature in Figure 16. If the slope of the curve (the Seebeck coefficient) is plotted vs. temperature, as in Figure 17, it becomes quite obvious that the thermocouple is a non-linear device.

A horizontal line in Figure 17 would indicate a constant α , in other words, a linear device. We notice that the slope of the type K thermocouple approaches a constant over a temperature range from 0° C to 1000° C. Consequently, the type K can be used with a multiplying voltmeter and an external ice point reference to obtain a moderately accurate direct readout of temperature. That is, the temperature display involves only a scale factor.

By examining the variations in Seebeck coefficient, we can easily see that using one constant scale factor would limit the temperature range of the system and restrict the system accuracy. Better conversion accuracy can be obtained by reading the voltmeter and consulting the NIST Thermocouple Tables⁴ (NIST Monograph 175 — see Table 3).

We could store these look-up table values in a computer, but they would consume an inordinate amount of memory. A more viable approach is to approximate the table values using a power series polynomial:

$$t_{90} = c_0 + c_1x + c_2x^2 + c_3x^3 + \dots + c_nx^n$$

where


t_{90} = Temperature

x = Thermocouple Voltage

c = Polynomial coefficients unique to each thermocouple

n = Maximum order of the polynomial

Figure 16
Thermocouple temperature vs. voltage graph



Type	Metals
	+ -
E	Chromel vs. Constantan
J	Iron vs. Constantan
K	Chromel vs. Alumel
R	Platinum vs. Platinum 13% Rhodium
S	Platinum vs. Platinum 10% Rhodium
T	Copper vs. Constantan

Figure 17
Seebeck coefficient vs. temperature




Table 3
Type E Thermocouple

Temperatures in °C (ITS-90)												
mV	.00	.01	.02	.03	.04	.05	.06	.07	.08	.09	.10	mV
0.00	0.00	0.17	0.34	0.51	0.68	0.85	1.02	1.19	1.36	1.53	1.70	0.00
0.10	1.70	1.87	2.04	2.21	2.38	2.55	2.72	2.89	3.06	3.23	3.40	0.10
0.20	3.40	3.57	3.74	3.91	4.08	4.25	4.42	4.59	4.76	4.92	5.09	0.20
0.30	5.09	5.26	5.43	5.60	5.77	5.94	6.11	6.28	6.45	6.61	6.78	0.30
0.40	6.78	6.95	7.12	7.29	7.46	7.63	7.79	7.96	8.13	8.30	8.47	0.40
0.50	8.47	8.64	8.80	8.97	9.14	9.31	9.48	9.64	9.81	9.98	10.15	0.50
0.60	10.15	10.32	10.48	10.65	10.82	10.99	11.15	11.32	11.49	11.66	11.82	0.60
0.70	11.82	11.99	12.16	12.33	12.49	12.66	12.83	12.99	13.16	13.33	13.50	0.70
0.80	13.50	13.66	13.83	14.00	14.16	14.33	14.50	14.66	14.83	15.00	15.16	0.80
0.90	15.16	15.33	15.50	15.66	15.83	16.00	16.16	16.33	16.49	16.66	16.83	0.90
1.00	16.83	16.99	17.16	17.32	17.49	17.66	17.82	17.99	18.15	18.32	18.49	1.00
1.10	18.49	18.65	18.82	18.98	19.15	19.31	19.48	19.64	19.81	19.98	20.14	1.10
1.20	20.14	20.31	20.47	20.64	20.80	20.97	21.13	21.30	21.46	21.63	21.79	1.20
1.30	21.79	21.96	22.12	22.29	22.45	22.61	22.78	22.94	23.11	23.27	23.44	1.30
1.40	23.44	23.60	23.77	23.93	24.10	24.26	24.42	24.59	24.75	24.92	25.08	1.40

As n increases, the accuracy of the polynomial improves. Lower order polynomials may be used over a narrow temperature range to obtain higher system speed. Table 4 is an example of the polynomials used in conjunction with software compensation for a data acquisition system. Rather than directly calculating the exponentials, the software is programmed to use the *nested polynomial* form to save execution time. The polynomial *fit* rapidly degrades outside the temperature range shown in Table 4 and should not be extrapolated outside those limits.

The calculation of high-order polynomials is a time consuming task, even for today's high-powered microprocessors. As we mentioned before, we can save time by using a lower order polynomial for a smaller temperature range. In the software for one data acquisition system, the thermocouple characteristic curve is divided into eight sectors and each sector is approximated by a third-order polynomial (Figure 18).

The data acquisition system measures the output voltage, categorizes it into one of the eight sectors, and chooses the appropriate coefficients for that sector. This technique is both faster and more accurate than the higher-order polynomial.

An even faster algorithm is used in many new data acquisition systems. Using many more sectors and a series of first order equations, they can make hundreds, even thousands, of internal calculations per second.

All the foregoing procedures assume the thermocouple voltage can be measured accurately and easily; however, a quick glance at Table 5 shows us that thermocouple output voltages are very small indeed. Examine the requirements of the system voltmeter.

Table 4
NIST ITS-90 Polynomial Coefficients

Thermocouple Type	Type J		Type K	
	Temperature Range Error Range Polynomial Order			
	-210° C to 0° C ± 0.05° C 8th order	0° C to 760° C ± 0.04° C 7th order	-200° C to 0° C ± 0.04° C 8th order	0° C to 500° C ± 0.05° C 9th order
C_0	0	0	0	0
C_2	1.9528268×10^{-2}	1.978425×10^{-2}	2.5173462×10^{-2}	2.508355×10^{-2}
C_1	$-1.2286185 \times 10^{-6}$	-2.001204×10^{-7}	$-1.1662878 \times 10^{-6}$	7.860106×10^{-8}
C_3	$-1.0752178 \times 10^{-9}$	1.036969×10^{-11}	$-1.0833638 \times 10^{-9}$	$-2.503131 \times 10^{-10}$
C_4	$-5.9086933 \times 10^{-13}$	$-2.549687 \times 10^{-16}$	$-8.9773540 \times 10^{-13}$	8.315270×10^{-14}
C_5	$-1.7256713 \times 10^{-16}$	3.585153×10^{-21}	$-3.7342377 \times 10^{-16}$	$-1.228034 \times 10^{-17}$
C_6	$-2.8131513 \times 10^{-20}$	$-5.344285 \times 10^{-26}$	$-8.6632643 \times 10^{-20}$	9.804036×10^{-22}
C_7	$-2.3963370 \times 10^{-24}$	5.099890×10^{-31}	$-1.0450598 \times 10^{-23}$	$-4.413030 \times 10^{-26}$
C_8	$-8.3823321 \times 10^{-29}$		$-5.1920577 \times 10^{-28}$	1.057734×10^{-30}
C_9				$-1.052755 \times 10^{-35}$

Temperature Conversion Equation: $t_{90} = c_0 + c_1x + c_2x^2 + \dots + c_9x^9$


Nested Polynomial Form (4th order example): $t_{90} = c_0 + x(c_1 + x(c_2 + x(c_3 + c_4x)))$

Table 5
Required DVM sensitivity

Thermocouple Type	Seebeck Coefficient at 25° C ($\mu\text{V}/^\circ\text{C}$)	DVM Sensitivity for 0.1° C (μV)
E	61	6.1
J	52	5.2
K	40	4.0
R	6	0.6
S	6	0.6
T	41	4.1

Even for the common type K thermocouple, the voltmeter must be able to resolve 4 μV to detect a 0.1° C change. This demands both excellent resolution (the more bits, the better) and measurement accuracy from the DMM. The magnitude of this signal is an open invitation for noise to creep into any system. For this reason instrument designers utilize several fundamental noise rejection techniques, including tree switching, normal mode filtering, integration and isolation.

Figure 18
Curve divided into sectors



Practical Thermocouple Measurement

Noise Rejection

Tree Switching - Tree switching is a method of organizing the channels of a scanner into groups, each with its own main switch.

Without tree switching, every channel can contribute noise directly through its stray capacitance. With tree switching, groups of parallel channel capacitances are in series with a single tree switch capacitance. The result is greatly reduced crosstalk in a large data acquisition system, due to the reduced interchannel capacitance (Figure 19).

Analog Filter - A filter may be used directly at the input of a voltmeter to reduce noise. It reduces interference dramatically, but causes the voltmeter to respond more slowly to step inputs (Figure 20).

Integration - Integration is an A/D technique which essentially averages noise over a full line cycle, thus power line-related noise and its harmonics are virtually eliminated. If the integration period is chosen to be less than an integer line cycle, its noise rejection properties are essentially negated.

Since thermocouple circuits that cover long distances are especially susceptible to power line related noise, it is advisable to use an integrating analog-to-digital converter to measure the thermocouple voltage. Integration is an especially attractive A/D technique in light of recent innovations have brought the cost in line with historically less expensive A/D technologies.

Figure 19
Tree switching





Figure 20
Analog filter



Isolation - A noise source that is common to both high and low measurement leads is called common mode noise. Isolated inputs help to reduce this noise as well as protect the measurement system from ground loops and transients (Figure 21).

Let's assume a thermocouple wire has been pulled through the same conduit as a 220V AC supply line. The capacitance between the power lines and the thermocouple lines will create an AC signal of approximately equal magnitude on both thermocouple wires. This is not a problem in an ideal circuit, but the voltmeter is not ideal. It has some capacitance between its low terminal and safety ground (earth). Current flows through this capacitance and through the thermocouple lead resistance, creating a normal mode signal which appears as measurement error.

This error is reduced by isolating the input terminals from safety ground with a careful design that minimizes the low-earth capacitance. Non-isolated or ground-referenced inputs ("single-ended" inputs are often ground-referenced) don't have the ability to reject common mode noise. Instead, the common mode current flows through the low lead directly to ground, causing potentially large reading errors.

Isolated inputs are particularly useful in eliminating ground loops created when the thermocouple junction comes into direct contact with a common mode noise source.

In Figure 22 we want to measure the temperature at the center of a molten metal bath that is being heated by electric current. The potential at the center of the bath is 120 VRMS. The equivalent circuit is shown in Figure 23.

Isolated inputs reject the noise current by maintaining a high impedance between LO and Earth. A non-isolated system, represented in Figure 24, completes the path to earth resulting in a ground loop. The resulting currents can be dangerously high

Figure 21
Isolation minimizes common mode current




Figure 22





Figure 23




and can be harmful to both instrument and operator. Isolated inputs are required for making measurements with high common mode noise.

Sometimes having isolated inputs isn't enough. In Figure 23, the voltmeter inputs are floating on a 120 VRMS common mode noise source. They must withstand a peak offset of ± 170 V from ground and still make accurate measurements. An isolated system with electronic FET switches typically can only handle ± 12 V of offset from earth; if used in this application, the inputs would be damaged.

The solution is to use commercially available external signal conditioning

Figure 24



(isolation transformers and amplifiers) that buffer the inputs and reject the common mode voltage. Another easy alternative is to use a data acquisition system that can float several hundred volts.

Notice that we can also minimize the noise by minimizing R_S . We do this by using larger thermocouple wire that has a smaller series resistance. Also, to reduce the possibility of magnetically induced noise, the thermocouple should be twisted in a uniform manner. Thermocouple extension wires are available commercially in a twisted pair configuration.

Practical Precautions

We have discussed the concepts of the reference junction, how to use a polynomial to extract absolute temperature data and what to look for in a data acquisition system to minimize the effects of noise. Now let's look at the thermocouple wire itself. The polynomial curve fit relies upon the thermocouple wire being perfect; that is, it must not become decalibrated during the act of making a temperature measurement. We shall now discuss some of the pitfalls of thermocouple thermometry.


Aside from the specified accuracies of the data acquisition system and its isothermal reference junction, most measurement error may be traced to one of these primary sources:

1. Poor junction connection
2. Decalibration of thermocouple wire
3. Shunt impedance and galvanic action
4. Thermal shunting
5. Noise and leakage currents
6. Thermocouple specifications
7. Documentation

Poor Junction Connection

There are a number of acceptable ways to connect two thermocouple wires: soldering, silver-soldering, welding, etc. When the thermocouple wires are soldered together, we introduce a third metal into the thermocouple circuit. As long as the temperatures on both sides of the thermocouple are the same, the solder should not introduce an error. The solder does limit the maximum temperature to which we can subject this junction (Figure 25). To reach a high measurement temperature, the joint must be welded. But welding is not a process to be taken lightly.⁵ Overheating can degrade the wire, and the welding gas and the atmosphere in which the wire is welded can both diffuse into the thermocouple metal, changing its characteristics. The difficulty is compounded by the very different nature of the two metals being joined.

Figure 25
Soldering a thermocouple



Commercial thermocouples are welded on expensive machinery using a capacitive-discharge technique to insure uniformity.


A poor weld can, of course, result in an open connection, which can be detected in a measurement situation by performing an open thermocouple check. This is a common test function available with many data loggers and data acquisition systems.

Decalibration

Decalibration is a far more serious fault condition than the open thermocouple because it can result in temperature reading that appears to be correct. Decalibration describes the process of unintentionally altering the physical makeup of the thermocouple wire so that it no longer conforms to the NIST polynomial within specified limits. Decalibration can result from diffusion of atmospheric particles into the metal, caused by temperature extremes. It can be caused by high temperature annealing or by cold-working the metal, an effect that can occur when the wire is drawn through a conduit or strained by rough handling or vibration. Annealing can occur within the section of wire that undergoes a temperature gradient.

Robert Moffat in his *Gradient Approach to Thermocouple Thermometry* explains that the thermocouple voltage is actually generated

Figure 26
Gradient produces voltage



by the section of wire that contains a temperature gradient, and not necessarily by the junction.⁹ For example, if we have a thermal probe located in a molten metal bath, there will be two regions that are virtually isothermal and one that has a large gradient.

In Figure 26, the thermocouple junction will not produce any part of the output voltage. The shaded section will be the one producing virtually the entire thermocouple output voltage. If, due to aging or annealing, the output of this thermocouple was found to be drifting, replacing only the thermocouple junction would not solve the problem. We would have to replace the entire shaded section, since it is the source of the thermocouple voltage.

Thermocouple wire obviously can't be manufactured perfectly; there will be some defects which will cause output voltage errors. These inhomogeneities can be especially disruptive if they occur in a region of steep temperature gradient.

Since we don't know where an imperfection will occur within a wire, the best thing we can do is to avoid creating a steep gradient. Gradients can be reduced by using metallic sleeving or by careful placement of the thermocouple wire.

Shunt Impedance

High temperatures can also take their toll on thermocouple wire insulators. Insulation resistance decreases exponentially with increasing temperature, even to the point that it creates a virtual junction. Assume we have a completely open thermocouple operating at a high temperature (Figure 27).

The leakage resistance, R_L can be sufficiently low to complete the circuit path and give us an improper voltage reading. Now let's assume the thermocouple is not open, but we are using a very long section of small diameter wire (Figure 28).


If the thermocouple wire is small, its series resistance, R_S , will be quite high and under extreme conditions $R_L \ll R_S$. This means that the thermocouple junction will appear to be at R_L and the output will be proportional to T_1 , not T_2 .

High temperatures have other detrimental effects on thermocouple wire. The impurities and chemicals within the insulation can actually diffuse into the thermocouple metal causing the temperature-voltage dependence to deviate from the published values. When using thermocouples at high temperatures, the insulation should be chosen carefully. Atmospheric effects can be minimized by choosing the proper protective metallic or ceramic sheath.

Galvanic Action

The dyes used in some thermocouple insulation will form an electrolyte in the presence of water. This creates a galvanic action, with a resultant output hundreds of times greater than the Seebeck effect. Precautions should be taken to shield the thermocouple wires from all harsh atmospheres and liquids.

Figure 27
Leakage resistance




Thermal Shunting

No thermocouple can be made without mass. Since it takes energy to heat any mass, the thermocouple will slightly alter the temperature it was meant to measure. If the mass to be measured is small, the thermocouple must naturally be small. But a thermocouple made with small wire is far more susceptible to the problems of contamination, annealing, strain, and shunt impedance.⁷ To minimize these effects, thermocouple extension wire can be used.

Extension wire is commercially available wire primarily intended to cover long distances between the measuring thermocouple and the voltmeter.

Extension wire is made of metals having Seebeck coefficients very similar to a particular thermocouple type. It is generally larger in size so that its series resistance does not become a factor when traversing long distances. It can also be pulled more readily through conduit than very small thermocouple wire. It generally is specified over a much lower temperature range than premium-grade thermocouple wire. In addition to offering a practical size advantage, extension wire is less expensive than standard thermocouple wire. This is especially true in the case of platinum-based thermocouples.

Figure 28
Virtual junction



Since the extension wire is specified over a narrower temperature range and it is more likely to receive mechanical stress, the temperature gradient across the extension wire should be kept to a minimum. This, according to the gradient theory, assures that virtually none of the output signal will be affected by the extension wire.

Noise - We have already discussed the line-related noise as it pertains to the data acquisition system. The techniques of integration, tree switching and isolation serve to cancel most line-related interference. Broadband noise can be rejected with an analog filter.

The one type of noise the data acquisition system cannot reject is a DC offset caused by a DC leakage current in the system. While it is less common to see DC leakage currents of sufficient magnitude to cause appreciable error, the possibility of their presence should be noted and prevented, especially if the thermocouple wire is very small and the related series impedance is high.

Wire Calibration

Thermocouple wire is manufactured to a certain specification signifying its conformance with the NIST tables. The specification can sometimes be enhanced by calibrating the wire (testing it at known temperatures). Consecutive pieces of wire on a continuous spool will generally track each other more closely than the specified tolerance, although their output voltages may be slightly removed from the center of the absolute specification.

If the wire is calibrated in an effort to improve its fundamental specifications, it becomes even more imperative that all of the aforementioned conditions be heeded in order to avoid decalibration.

Documentation

It may seem incongruous to speak of documentation as being a source of voltage measurement error, but the fact is that thermocouple systems, by their very ease of use, invite a large number of data points. The sheer magnitude of the data can become quite unwieldy. When a large amount of data is taken, there is an increased probability of error due to mislabeling of lines, using the wrong NIST curve, etc.

Since channel numbers invariably change, data should be categorized by measurand, not just channel number.¹⁰ Information about any given measurand, such as transducer type, output voltage, typical value, and location can be maintained in a data file. This can be done under PC control or simply by filling out a preprinted form. No matter how the data is maintained, the importance of a concise system should not be underestimated, especially at the outset of a complex data gathering project.

Diagnostics

Most of the sources of error that we have mentioned are aggravated by using the thermocouple near its temperature limits. These conditions will be encountered infrequently in most applications. But what about the situation where we are using small thermocouples in a harsh atmosphere at high temperatures? How can we tell when the thermocouple is producing erroneous results? We need to develop a reliable set of diagnostic procedures.

Through the use of diagnostic techniques, R.P. Reed has developed an excellent system for detecting a faulty thermocouple and data channels.¹⁰ Three components of this system are the event record, the zone box test and the thermocouple resistance history.

Event Record - The first diagnostic is not a test at all, but a recording of all pertinent events that could even remotely affect the measurements. An example is:

Figure 29
March 18 Event Record

10:43	Power failure
10:47	System power returned
11:05	Changed M821 to type K thermocouple
13:51	New data acquisition program
16:07	M821 appears to be bad reading

We look at our program listing and find that measurand #M821 uses a type J thermocouple and that our new data acquisition program interprets it as type J. But from the event record, apparently thermocouple #M821 was changed to a type K, and the change was not entered into the program. While most anomalies are not discovered this easily, the event record can provide valuable insight into the reason for an unexplained change in a system measurement. This is especially true in a system configured to measure hundreds of data points.

Zone Box Test - The zone box is an isothermal terminal block with a known temperature used in place of an ice bath reference. If we temporarily short-circuit the thermocouple directly at the zone box, the system should read a temperature very close to that of the zone box, i.e., close to room temperature (Figure 30).

If the thermocouple lead resistance is much greater than the shunting resistance, the copper wire shunt forces $V = 0$. In the normal unshorted case, we want to measure T_J , and the system reads:

$$V = \alpha(T_J - T_{REF})$$

But, for the functional test, we have shorted the terminals so that $V = 0$. The indicated temperature T_J is thus:

$$0 = \alpha(T_J - T_{REF})$$

$$T_J = T_{REF}$$

Thus, for a DVM reading of $V = 0$, the system will indicate the zone box temperature. First we observe the temperature T_J (forced to be different from T_{REF}), then we short the thermocouple with a copper wire and make sure that the system indicates the zone box temperature instead of T_J .

This simple test verifies that the controller, scanner, voltmeter and zone box compensation are all operating correctly. In fact, this simple procedure tests everything but the thermocouple wire itself.

Figure 30
Shorting the thermocouples at the terminals






Figure 31
Burning coal seam



Thermocouple Resistance - A sudden change in the resistance of a thermocouple circuit can act as a warning indicator. If we plot resistance vs. time for each set of thermocouple wires, we can immediately spot a sudden resistance change, which could be an indication of an open wire, a wire shorted due to insulation failure, changes due to vibration fatigue or one of many failure mechanisms.

For example, assume we have the thermocouple measurement shown in Figure 31.

Figure 32
Thermocouple resistance vs. time



We want to measure the temperature profile of an underground seam of coal that has been ignited. The wire passes through a high temperature region, into a cooler region. Suddenly, the temperature we measure rises from 300°C to 1200°C . Has the burning section of the coal seam migrated to a different location, or has the thermocouple insulation failed, thus causing a short circuit between the two wires at the point of a hot spot?


If we have a continuous history of the thermocouple wire resistance, we can deduce what has actually happened (Figure 32).

The resistance of the thermocouple will naturally change with time as the resistivity of the wire changes due to varying temperatures. But a sudden change in resistance is an indication that something is wrong. In this case, the resistance has dropped abruptly, indicating that the insulation has failed, effectively shortening the thermocouple loop (Figure 33).

The new junction will measure temperature T_S , not T_1 . The resistance measurement has given us additional information to help interpret the physical phenomenon that has occurred. This failure would not have been detected by a standard open-thermocouple check.

Measuring Resistance - We have casually mentioned checking the resistance of the thermocouple wire, as if it were a straightforward measurement. But keep in mind that when the thermocouple is producing a voltage, this voltage can cause a large resistance measurement error. Measuring the resistance of a thermocouple is akin to measuring the internal resistance of a battery. We can attack this problem with a technique known as *offset compensated ohms measurement*.

Figure 33
Cause of the resistance change




As the name implies, the data acquisition unit first measures the thermocouple offset voltage without the ohms current source applied. Then the ohms current source is switched on and the voltage across the resistance is again measured. The instrument firmware compensates for the offset voltage of the thermocouple and calculates the actual thermocouple source resistance.

Special Thermocouples - Under extreme conditions, we can even use diagnostic thermocouple circuit configurations. *Tip-branched* and *leg-branched* thermocouples are four-wire thermocouple circuits that allow redundant measurement of temperature, noise voltage and resistance for checking wire integrity (Figure 34). Their respective merits are discussed in detail in Bibliography 8.

Only severe thermocouple applications require such extensive diagnostics, but it is comforting to know that there are procedures that can be used to verify the integrity of an important thermocouple measurement.

Figure 34



Summary

In summary, the integrity of a thermocouple system may be improved by following these precautions:

- Use the largest wire possible that will not shunt heat away from the measurement area.
- If small wire is required, use it only in the region of the measurement and use extension wire for the region with no temperature gradient.
- Avoid mechanical stress and vibration, which could strain the wires.
- When using long thermocouple wires, use shielded, twisted pair extension wire.
- Avoid steep temperature gradients.
- Try to use the thermocouple wire well within its temperature rating.
- Use an integrating A/D converter with high resolution and good accuracy.
- Use isolated inputs with ample offset capability.
- Use the proper sheathing material in hostile environments to protect the thermocouple wire.
- Use extension wire only at low temperatures and only in regions of small gradients.
- Keep an event log and a continuous record of thermocouple resistance.

The RTD

History

The same year that Seebeck made his discovery about thermoelectricity, Sir Humphrey Davy announced that the resistivity of metals showed a marked temperature dependence. Fifty years later, Sir William Siemens proffered the use of platinum as the element in a resistance thermometer. His choice proved most propitious, as platinum is used to this day as the primary element in all high-accuracy resistance thermometers. In fact, the platinum resistance temperature detector, or PRTD, is used today as an interpolation standard from the triple point of equilibrium hydrogen ($-259.3467^{\circ}\text{C}$) to the freezing point of silver (961.78°C).

Platinum is especially suited to this purpose, as it can withstand high temperatures while maintaining excellent stability. As a noble metal, it shows limited susceptibility to contamination.

The classical resistance temperature detector (RTD) construction using platinum was proposed by C.H. Meyers in 1932.¹² He wound a helical coil of platinum on a crossed mica web and mounted the assembly inside a glass tube. This construction minimized strain on the wire while maximizing resistance (Figure 35).

Although this construction produces a very stable element, the thermal contact between the platinum and the measured point is quite poor. This results in a slow thermal response time. The fragility of the structure limits its use today primarily to that of a laboratory standard.

Another laboratory standard has taken the place of the Meyer's design. This is the *bird-cage* element proposed by Evans and Burns.¹⁶ The platinum element remains largely unsupported, which allows it to move freely when expanded or contracted by temperature variations (Figure 36).

Figure 35
Meyers RTD
construction






Figure 36
Bird-caged
PRTD




Strain-induced resistance changes caused by time and temperature are thus minimized and the bird-cage becomes the ultimate laboratory standard. Due to the unsupported structure and subsequent susceptibility to vibration, this configuration is still a bit too fragile for industrial environments.

A more rugged construction technique is shown in Figure 37. The platinum wire is bifilar wound on a glass or ceramic bobbin. The bifilar winding reduces the effective enclosed area of the coil to minimize magnetic pickup and its related noise. Once the wire is wound onto the bobbin, the assembly is then sealed with a coating of molten glass. The sealing process assures that the RTD will maintain its integrity


Figure 37



Sealed Bifilar Winding



Helical RTD



Film RTD

under extreme vibration, but it also limits the expansion of the platinum metal at high temperatures. Unless the coefficients of expansion of the platinum and the bobbin match perfectly, stress will be placed on the wire as the temperature changes, resulting in a strain-induced resistance change. This may result in a permanent change in the resistance of the wire.

There are partially supported versions of the RTD which offer a compromise between the bird-cage approach and the sealed helix. One such approach uses a platinum helix threaded through a ceramic cylinder and affixed via glass-frit. These devices will maintain excellent stability in moderately rugged vibrational applications.

Metal Film RTD's

In the newest construction technique, a platinum or metal-glass slurry film is deposited or screened onto a small flat ceramic substrate, etched with a laser-trimming system, and sealed. The film RTD offers substantial reduction in assembly time and has the further advantage of increased resistance for a given size. Due to the manufacturing technology, the device size itself is small, which means it can respond quickly to step changes in temperature. Film RTD's are less stable than their wire-wound counterparts, but they are more popular because of their decided advantages in size, production cost and ruggedness.

Metals - All metals produce a positive change in resistance for a positive change in temperature. This, of course, is the main function of an RTD. As we shall soon see, system error is minimized when the nominal value of the RTD resistance is large. This implies a metal wire with a high resistivity. The lower the resistivity of the metal, the more material we will have to use.

Table 6 lists the resistivities of common RTD materials.

Because of their lower resistivities, gold and silver are rarely used as RTD elements. Tungsten has a relatively high resistivity, but is reserved for very high temperature applications because it is extremely brittle and difficult to work.

Copper is used occasionally as an RTD element. Its low resistivity forces the element to be longer than a platinum element, but its linearity and very low cost make it an economical alternative. Its upper temperature limit is only about 120° C.

Figure 38
Effect of lead resistance




Table 6


Metal		Resistivity Ω /CMF (cmf = circular mil foot)
Gold	Au	13.00
Silver	Ag	8.8
Copper	Cu	9.26
Platinum	Pt	59.00
Tungsten	W	30.00
Nickel	Ni	36.00

The most common RTD's are made of either platinum, nickel, or nickel alloys. The economical nickel derivative wires are used over a limited temperature range. They are quite non-linear and tend to drift with time. For measurement integrity, platinum is the obvious choice.

Resistance Measurement

The common values of resistance for a platinum RTD range from 10 ohms for the bird-cage model to several thousand ohms for the film RTD. The single most common value is 100 ohms at 0° C. The DIN 43760 standard temperature coefficient of platinum wire is $\alpha = .00385$. For a 100 ohm wire this corresponds to $+0.385 \Omega/^{\circ}\text{C}$ at 0° C. This value for α is actually the

Figure 39
Wheatstone bridge



average slope from 0° C to 100° C. The more chemically pure platinum wire used in platinum resistance standards has an α of $+0.00392 \text{ ohms/ohm/}^{\circ}\text{C}$.

Both the slope and the absolute value are small numbers, especially when we consider the fact that the measurement wires leading to the sensor may be several ohms or even tens of ohms. A small lead impedance can contribute a significant error to our temperature measurement (Figure 38).

A 10 ohm lead impedance implies $10/.385 \cong 26^{\circ}\text{C}$ error in our measurement. Even the temperature coefficient of the lead wire can contribute a measurable error. The classical method of avoiding this problem has been the use of a bridge (Figure 39).

The bridge output voltage is an indirect indication of the RTD resistance. The bridge requires four connection wires, an external source, and three resistors that have a zero temperature coefficient. To avoid subjecting the three bridge-completion resistors to the same temperature as the RTD, the RTD is separated from the bridge by a pair of extension wires (Figure 40).





Figure 41
3-Wire Bridge



These extension wires recreate the problem that we had initially: The impedance of the extension wires affects the temperature reading. This effect can be minimized by using a *three-wire bridge configuration* (Figure 41).


If wires A and B are perfectly matched in length, their impedance effects will cancel because each is in an opposite leg of the bridge. The third wire, C, acts as a sense lead and carries no current.

The Wheatstone bridge shown in Figure 41 creates a non-linear relationship between resistance change and bridge output voltage change. This compounds the already non-linear temperature-resistance characteristic of the RTD by requiring an additional equation to convert bridge output voltage to equivalent RTD impedance.

4-Wire Ohms - The technique of using a current source along with a remotely sensed digital voltmeter alleviates many problems associated with the bridge. Since no current flows through the voltage sense leads, there is no IR drop in these leads and thus no lead resistance error in the measurement.

The output voltage read by the DVM is directly proportional to RTD resistance, so only one conversion equation is necessary. The three bridge-completion resistors are replaced by one reference resistor. The digital voltmeter measures only the voltage dropped across the RTD and is insensitive to the length of the lead wires (Figure 42).

Figure 42
4-Wire Ohms Measurement



The one disadvantage of using 4-wire ohms is that we need one more extension wire than the 3-wire bridge. This is a small price to pay if we are at all concerned with the accuracy of the temperature measurement.

Resistance to Temperature Conversion

The RTD is a more linear device than the thermocouple, but it still requires curve-fitting. The Callendar-Van Dusen equation has been used for years to approximate the RTD curve.^{11, 13}

$$R_T = R_0 + R_0 \alpha \left[T - \delta \left(\frac{T}{100} - 1 \right) \left(\frac{T}{100} \right) - \beta \left(\frac{T}{100} - 1 \right) \left(\frac{T}{100} \right)^3 \right]$$

Where:

- R_T = resistance at temperature T
- R_0 = resistance at $T = 0^\circ \text{C}$
- α = temperature coefficient at $T = 0^\circ \text{C}$
(typically $+ 0.00392 \Omega / \Omega / ^\circ \text{C}$)
- $\delta = 1.49$ (typical value for .00392 platinum)
- $\beta = 0 \quad T > 0$
 0.11 (typical) $T < 0$

The exact values for coefficients α , δ and β are determined by testing the RTD at four temperatures and solving the resultant equations. This familiar equation was replaced in 1968 by a 20th order polynomial in order to provide a more accurate curve fit.

The plot of this equation shows the RTD to be a more linear device than the thermocouple (Figure 43).


Practical Precautions

The same practical precautions that apply to thermocouples also apply to RTD's, i.e., use shields and twisted-pair wire, use proper sheathing, avoid stress and steep-gradients, use large extension wire, keep good documentation and use an integrating DMM. In addition, the following precautions should be observed.

Construction - Due to its construction, the RTD is somewhat more fragile than the thermocouple, and precautions must be taken to protect it.

Self-Heating - Unlike the thermocouple, the RTD is not self-powered. A current must be passed through the device to provide a voltage that can be measured. The current causes Joule (I^2R) heating within the RTD, changing its temperature. This self-heating appears as a measurement error. Consequently, attention must be paid

Figure 43



Small RTD

Fast Response Time
Low Thermal Shunting
High Self-heating Error

Large RTD

Slow Response Time
Poor Thermal Shunting
Low Self-heating Error

to the magnitude of the measurement current supplied by the ohmmeter. A typical value for self-heating error is $\frac{1}{2}^{\circ}\text{C}$ per milliwatt in free air. Obviously, an RTD immersed in a thermally conductive medium will distribute its Joule heat to the medium and the error due to self-heating will be smaller. The same RTD that rises 1°C per milliwatt in free air will rise only $1/10^{\circ}\text{C}$ per milliwatt in air which is flowing at the rate of one meter per second.⁶

To reduce self-heating errors, use the minimum ohms measurement current that will still give the resolution you

require, and use the largest RTD you can that will still give good response time. Obviously, there are compromises to be considered.

Thermal Shunting - Thermal shunting is the act of altering the measurement temperature by inserting a measurement transducer. Thermal shunting is more a problem with RTD's than with thermocouples, as the physical bulk of an RTD is greater than that of a thermocouple.

Thermal EMF - The platinum-to-copper connection that is made when the RTD is measured can cause a thermal offset voltage. The offset-compensated ohms technique can be used to eliminate this effect.

The Thermistor

Like the RTD, the thermistor is also a temperature-sensitive resistor. While the thermocouple is the most versatile temperature transducer and the PRTD is the most stable, the word that best describes the thermistor is *sensitive*. Of the three major categories of sensors, the thermistor exhibits by far the largest parameter change with temperature.

Thermistors are generally composed of semiconductor materials. Although positive temperature coefficient units are available, most thermistors have a negative temperature coefficient (TC); that is, their resistance decreases with increasing temperature. The negative TC can be as large as several percent per degree C, allowing the thermistor circuit to detect minute changes in temperature which could not be observed with an RTD or thermocouple circuit.

The price we pay for this increased sensitivity is loss of linearity. The thermistor is an extremely non-linear device which is highly dependent upon process parameters. Consequently, manufacturers have not standardized thermistor curves to the extent that RTD and thermocouple curves have been standardized (Figure 44).

An individual thermistor curve can be very closely approximated through use of the Steinhart-Hart equation:¹⁸

$$\frac{1}{T} = A + B(\ln R) + C(\ln R)^3$$

where:


T = kelvins

R = Resistance of the thermistor

A,B,C = curve-fitting constants

A, B, and C are found by selecting three data points on the published data curve and solving the three simultaneous equations. When the data points are chosen to span no more than 100° C within the nominal center of the thermistor's temperature range, this equation approaches a rather remarkable $\pm .02^\circ$ C curve fit.

Figure 44



Somewhat faster computer execution time is achieved through a simpler equation:

$$T = \frac{1}{(\ln R) - A} - C$$

where A, B, and C are again found by selecting three (R,T) data points and solving the three resultant simultaneous equations. This equation must be applied over a narrower temperature range in order to approach the accuracy of the Steinhart-Hart equation.

Measurement

The high resistivity of the thermistor affords it a distinct measurement advantage. The four-wire resistance measurement may not be required as it is with RTD's. For example, a common thermistor value is 5000Ω at 25° C. With a typical TC of 4%/° C, a measurement lead resistance of 10Ω produces only .05° C error. This error is a factor of 500 times less than the equivalent RTD error.

Disadvantages - Because they are semiconductors, thermistors are more susceptible to permanent decalibration at high temperatures than are RTD's or thermocouples. The use of thermistors is generally limited to a few hundred degrees Celsius, and manufacturers warn that extended exposures even well below maximum operating limits will cause the thermistor to drift out of its specified tolerance.

Thermistors can be made very small which means they will respond quickly to temperature changes. It also means that their small thermal mass makes them especially susceptible to self-heating errors. Thermistors are a good deal more fragile than RTD's or thermocouples and they must be carefully mounted to avoid crushing or bond separation.


Monolithic Linear Temperature Sensor

An innovation in thermometry is the integrated circuit temperature transducer. These are available in both voltage and current-output configurations. Both supply an output that is linearly proportional to absolute temperature. Typical values are $1 \mu\text{A/K}$ and 10 mV/K F (Figure 45).

Some integrated sensors even represent temperature in a digital output format that can be read directly by a microprocessor.

Except that they offer a very linear output with temperature, these IC sensors share all the disadvantages of thermistors. They are semiconductor devices and thus have a limited temperature range. The same problems of self-heating and fragility are evident and they require an external power source.

These devices provide a convenient way to produce an easy-to-read output that is proportional to temperature. Such a need arises in thermocouple reference junction hardware, and in fact these devices are increasingly used for thermocouple compensation.



The Measurement System

Figure 46 shows a practical method of implementing a thermocouple reference junction. The arrow points to an IC sensor which is used to perform software thermocouple compensation.

Conversion routines built into the Agilent 34970A firmware accept B, E, J, K, N, R, S and T type thermocouples, 2.2k Ω , 5k Ω and 10k Ω thermistors, as well as a wide range of RTD's. Results are displayed directly in degrees C, F or kelvins.

The Agilent 34970A data acquisition system incorporates all of the desirable features mentioned in this application note:

- Internal 6½ digit DMM
- Integrating A/D for noise rejection
- Low-thermal scanning with built-in thermocouple reference junctions
- Open thermocouple check
- Built-in thermocouple, thermistor, and RTD linearization routines with ITS-90 conformity
- Four-wire Ohms function with offset compensation
- Isolated inputs that float up to 300 V

The Agilent 34970A comes standard with RS-232 and GPIB interfaces, 50,000 readings of non-volatile memory for stand-alone data logging, and Agilent Benchlink Data Logger software for easy PC-based testing. Plus, its flexible three-slot construction makes it easy to add channels for changing applications.

Figure 46
General purpose multiplexer module for the Agilent 34970A Data Acquisition/Switch Unit




Figure 47
Agilent 34970A Data Acquisition/Switch Unit



The Agilent DAC1000 data acquisition and control system (Figure 48), another example solution, provides high-speed temperature measurements where point count is high. When configured for temperature measurements, it consists of:

- E1419A scanning analog-to-digital converter (ADC) module with 64 channels that can be configured for temperature measurements. Scanning rate is 56,000 channels/s. Several hundred channel configurations are possible with multiple modules.
- Signal conditioning plug-on (SCP) that rides piggy-back on the ADC module provides input for thermocouples.
- External terminal block with built-in thermocouple reference junction and terminal connections to the application.
- Four-wire Ohms SCP with offset compensation for RTD and thermistor measurements.
- Built-in engineering unit conversions for thermocouple, thermistor, and RTD measurements.

Figure 48
Agilent DAC1000
System



This VXI-based system offers much more than temperature measurements. It provides a wide variety of analog/digital input and output capability required by designers of electro-mechanical products and manufacturers needing stringent monitoring and control of physical processes. The DAC1000 is a recommended configuration consisting of the E1419A, 6-slot VXI mainframe, GPIB interfaces, and Agilent VEE for the PC. Agilent VEE, a powerful time-saving graphical programming language, is programmed by connecting a few icons or objects resembling a block diagram.

Agilent VEE provides data collection, test reporting and a friendly graphical user interface.

Agilent also offers other VXI-based solutions for temperature measurements. Product choices range from small compact systems for portable or remote operation to high-speed scanning systems that also provide advanced control and analysis capabilities.

Summary


Reliable temperature measurements require a great deal of care in both selecting and using the transducer, as well as choosing the right measurement system. With proper precautions observed for self-heating, thermal shunting, transducer decalibration, specifications and noise reduction, even the most complex temperature monitoring project will produce repeatable, reliable data. Today's data acquisition system assumes a great deal of this burden, allowing us to concentrate on meaningful test results.

Appendix A

The Empirical Laws of Thermocouples²


The following examples illustrate the empirically derived laws of thermocouples which are useful in understanding and diagnosing thermocouple circuits.

The Law of Intermediate Metals




Inserting the copper lead between the iron and constantan leads will not change the output voltage V , regardless of the temperature of the copper lead. The voltage V is that of an Fe-C thermocouple at temperature T_1 .

The Law of Interior Temperatures



The output voltage V will be that of an Fe-C thermocouple at temperature T , regardless of the external heat source applied to either measurement lead.

The Law of Inserted Metals



The voltage V will be that of an Fe-C thermocouple at temperature T , provided both ends of the platinum wire are at the same temperature. The two thermocouples created by the platinum wire (Fe-Pt and Pt-Fe) act in opposition.

All of the above examples assume the measurement wires are homogeneous; that is, free of defects and impurities.

Appendix B

Thermocouple Characteristics

Over the years specific pairs of thermocouple alloys have been developed to solve unique measurement problems. Idiosyncrasies of the more common thermocouples are discussed here.


We will use the term “standard wire error” to refer to the common commercial specification published in the *Annual Book of ASTM Standards*. It represents the allowable deviation between the actual thermocouple output voltage and the voltage predicted by the tables in NIST Monograph 175.

Noble Metal Thermocouples -

The noble metal thermocouples, types B, R, and S, are all platinum or platinum-rhodium thermocouples and hence share many of the same characteristics.

Diffusion - Metallic vapor diffusion at high temperatures can readily change the platinum wire calibration, hence platinum wires should only be used inside a non-metallic sheath such as high-purity alumina. The one exception to this rule is a sheath made of platinum, and this option is prohibitively expensive.

Stability - The platinum-based couples are by far the most stable of all the common thermocouples. Type S is so stable that it is specified as the standard for temperature calibration between the antimony point (630.74°C) and the gold point (1064.43°C).



Type B - The B couple is the only common thermocouple that exhibits a double-valued ambiguity.

Due to the double-valued curve and the extremely low Seebeck coefficient at low temperatures, Type B is virtually useless below 50°C . Since the output is nearly zero from 0°C to 42°C , Type B has the unique advantage that the reference junction temperature is almost immaterial, as long as it is between 0°C and 40°C . Of course, the measuring junction temperature is typically very high.

Base Metal Thermocouples

Unlike the noble metal thermocouples, the base metal couples have no specified chemical composition. Any combination of metals may be used which results in a voltage vs. temperature curve fit that is within the standard wire errors. This leads to some rather interesting metal combinations. Constantan, for example, is not a specific metal alloy at all, but a generic name for a whole series of copper-nickel alloys. Incredibly, the Constantan used in a type T (copper-Constantan) thermocouple is not the same as the Constantan used in the type J (iron-Constantan) thermocouple.³

Type E - Although Type E standard wire errors are not specified below 0°C , the type E thermocouple is ideally suited for low temperature measurements because of its high Seebeck coefficient ($58\text{ V}/^{\circ}\text{C}$), low thermal conductivity and corrosion resistance.

The Seebeck coefficient for Type E is greater than all other standard couples, which makes it useful for detecting small temperature changes.

Type J - Iron, the positive element in a J thermocouple is an inexpensive metal rarely manufactured in pure form. J thermocouples are subject to poor conformance characteristics because of impurities in the iron. Even so, the J thermocouple is popular because of its high Seebeck coefficient and low price.

The J thermocouple should never be used above 760°C due to an abrupt magnetic transformation that can cause decalibration even when returned to lower temperatures.


Type T - This is the only thermocouple with published standard wire errors for the temperature region below 0° C; however, type E is actually more suitable at very low temperatures because of its higher Seebeck coefficient and lower thermal conductivity.

Type T has the unique distinction of having one copper lead. This can be an advantage in a specialized monitoring situation where a temperature difference is all that is desired.

The advantage is that the copper thermocouple leads are the same metal as the DVM terminals, making lead compensation unnecessary.

Types K & N - Type K has long been a popular thermocouple. It is especially suited to higher temperature applications due to its resistance to oxidation.

The type N thermocouple is gaining popularity as a replacement for type K. It has a slightly lower output (smaller Seebeck coefficient) than type K, but an even higher resistance to oxidation. The type N thermocouple output curve is dependent upon wire size, and there are two distinct Nicrosil-Nisil characteristic curves published in NIST Monograph 175, the differences being wire size and temperature range.¹⁴



Tungsten - There are three common types of tungsten thermocouples. All are alloyed with rhenium to make the metal more malleable.

Type G* W vs W-26% Re


Type C* W-5% Re vs W-26% Re

Type D* W-3% Re vs W-25% Re


Tungsten thermocouples are used for measuring very high temperatures in either a vacuum or an inert atmosphere.

* not ANSI symbols

Thermocouple Hardware



Connector
Composed of same metals as thermocouple, for minimum connection error.



Thermocouple Well

- lower gradient
- protects wire
- change thermocouple without interrupting process



Underground Junction

- best protection
- electrically isolated




Grounded Junction

- wires protected
- faster response



Exposed Junction

- wires unprotected
- fastest response



Thermocouple Washers

- couple built into washer
- convenient mounting

Type	Metal		Standard U.S. Color Code		Ω /Double Foot@ 20° C 20 AWG	Seebeck Coefficient S(μ V/°C)@T(°C)		Wire Error in °C			NIST Specified Material Range [†] (°C)
	+	-	+	-		Range	Standard	Special			
B	Platinum-30% Rhodium	Platinum-6% Rhodium	Gray	Red	0.22	5.96	600	870 to 1700	± 0.5%	± 0.25%	0 to 1820
E	Nickel-10% Chromium	Constantan	Violet	Red	0.71	58.67	0	0 to 900	± 1.7 or ± 0.5%	± 1 or ± 0.4%	-270 to 1000
J	Iron	Constantan	White	Red	0.36	50.38	0	0 to 750	± 2.2 or ± 0.75%	± 1.1 or ± 0.4%	-210 to 1200
K	Nickel-10% Chromium	Nickel	Yellow	Red	0.59	39.45	0	0 to 1250	± 2.2 or ± 0.75%	± 1.1 or ± 0.4%	-270 to 1372
N	Nicrosil	Nisil	Orange	Red	0.78	25.93	0	0 to 1250	± 2.2 or ± 0.75%	± 1.1 or ± 0.4%	-270 to 1300
R	Platinum-13% Rhodium	Platinum	Black	Red	0.19	11.36	600	0 to 1450	± 1.5 or ± 0.25%	± 0.6 or ± 0.1%	-50 to 1768
S	Platinum-10% Rhodium	Platinum	Black	Red	0.19	10.21	600	0 to 1450	± 1.5 or ± 0.25%	± 0.6 or ± 0.1%	-50 to 1768
T	Copper	Constantan	Blue	Red	0.30	38.75	0	0 to 350	± 1 or ± 0.75%	± 0.5 or ± 0.4%	-270 to 400

[†]Material range is for 8 AWG wire and decreases with decreasing wire size.

Bibliography

1. Charles Herzfeld, F.G. Brickwedde: *Temperature - Its Measurement and Control in Science and Industry*, Vol. 3, Part 1, Reinhold, New York, 1962.
2. Robert P. Benedict: *Fundamentals of Temperature, Pressure and Flow Measurements*, John Wiley & Sons, Inc., New York, 1969.
3. *Manual on the Use of Thermocouples in Temperature Measurement, Fourth Edition*, Revision of ASTM Special Publication 470B, Philadelphia, PA., 1993.
4. *Temperature-Electromotive Force Reference Functions and Tables for the Letter-Designated Thermocouple Types Based on the ITS-90*, NIST Monograph 175, National Institute of Standards and Technology, Washington, D.C., 1993
5. H. Dean Baker, E.A. Ryder, N.H. Baker: *Temperature Measurement in Engineering*, Omega Press, Division of Omega Engineering Inc.
6. *Temperature Measurement Handbook 1983*, Omega Engineering, Stamford, Connecticut, 06907.
7. R.L. Anderson: *Accuracy of Small Diameter Sheathed Thermocouples for the Core Flow Test Loop*, Oak Ridge National Laboratories, ORNL-5401, (available from National Information Service), April, 1979.
8. R.P. Reed: *Branched Thermocouple Circuits in Underground Coal Gasification Experiments*, Proceedings of the 22nd ISA International Instrumentation Symposium, Instrument Society of America, 1976.
9. R.J. Moffat: *The Gradient Approach to Thermocouple Circuitry, from Temperature - Its Measurement and Control in Science and Industry*, Reinhold, New York, 1962.
10. R.P. Reed: *A Diagnostics-oriented System for Thermocouple Thermometry*, Proceedings of 24th ISA International Instrumentation Symposium, Instrument Society of America, 1978.
11. Harry R. Norton: *Handbook of Transducers for Electronic Measuring Systems*, Prentice-Hall, Englewood Cliffs, New Jersey.
12. C.H. Meyers: *Coiled Filament Resistance Thermometers*, NBS Journal of Research, Vol. 9, 1932.
13. Bulletin 9612, Rev. B: *Platinum Resistance Temperature Sensors*, Rosemount Engineering Co., 1962.
14. Burley, Powell, Burns, & Scroger: *The Nicrosil vs. Nisil Thermocouple: Properties and Thermoelectric Reference Data*, NBS Monograph 161, U.S. Dept. of Commerce, Washington, D.C., 1978.
15. J.P. Tavener: *Platinum Resistance Temperature Detectors - State of the Art, Measurements & Control*, Measurements & Data Corporation, Pittsburgh, PA., April 1974.
16. J.P. Evans and G.W. Burns: *A Study of Stability of High Temperature Platinum Resistance Thermometers, in Temperature - Its Measurement and Control in Science and Industry*, Reinhold, New York, 1962.
17. D.D. Pollock: *The Theory and Properties of Thermocouple Elements*, ASTM STP 492, Omega Press, Ithaca, New York, 1979.
18. *YSI Precision Thermistors*, Yellow Springs Instruments, Inc., Yellow Springs, Ohio, 1977.
19. R.P. Reed: *Thermoelectric Thermometry. A Functional Model, from Temperature - Its Measurement and Control in Science and Industry*, Vol. 5, American Institute of Physics, N.Y. 1982.

Agilent Technologies' Test and Measurement Support, Services, and Assistance

Agilent Technologies aims to maximize the value you receive, while minimizing your risk and problems. We strive to ensure that you get the test and measurement capabilities you paid for and obtain the support you need. Our extensive support resources and services can help you choose the right Agilent products for your applications and apply them successfully. Every instrument and system we sell has a global warranty. Support is available for at least five years beyond the production life of the product. Two concepts underlie Agilent's overall support policy: "Our Promise" and "Your Advantage."

Our Promise

Our Promise means your Agilent test and measurement equipment will meet its advertised performance and functionality. When you are choosing new equipment, we will help you with product information, including realistic performance specifications and practical recommendations from experienced test engineers. When you use Agilent equipment, we can verify that it works properly, help with product operation, and provide basic measurement assistance for the use of specified capabilities, at no extra cost upon request. Many self-help tools are available.

Your Advantage

Your Advantage means that Agilent offers a wide range of additional expert test and measurement services, which you can purchase according to your unique technical and business needs. Solve problems efficiently and gain a competitive edge by contracting with us for calibration, extra-cost upgrades, out-of-warranty repairs, and on-site education and training, as well as design, system integration, project management, and other professional engineering services. Experienced Agilent engineers and technicians worldwide can help you maximize your productivity, optimize the return on investment of your Agilent instruments and systems, and obtain dependable measurement accuracy for the life of those products.

For More Assistance with Your Test & Measurement Needs go to

www.agilent.com/find/assist

Or contact the test and measurement experts at Agilent Technologies
(During normal business hours)

United States:
(tel) 1 800 452 4844

Latin America:
(tel) (305) 267 4245
(fax) (305) 267 4286

Canada:
(tel) 1 877 894 4414
(fax) (905) 206 4120

Australia:
(tel) 1 800 629 485
(fax) (61 3) 9272 0749

Europe:
(tel) (31 20) 547 2323
(fax) (31 20) 547 2390

New Zealand:
(tel) 0 800 738 378
(fax) 64 4 495 8950

Japan:
(tel) (81) 426 56 7832
(fax) (81) 426 56 7840

Asia Pacific:
(tel) (852) 3197 7777
(fax) (852) 2506 9284

Product specifications and descriptions in this document subject to change without notice.
Copyright © 1997, 2000 Agilent Technologies
Printed in U.S.A. 8/00
5965-7822E



Agilent Technologies

Innovating the HP Way

* This section contains coefficients for type B thermocouples for
 * the two subranges of temperature listed below. The coefficients
 * are in units of °C and mV and are listed in the order of constant
 * term up to the highest order. The equation is of the form
 * $E = \sum_{i=0}^n c_i t^i$.

*
 * Temperature Range (°C)
 * 0.000 to 630.615
 * 630.615 to 1820.000

name: reference function on ITS-90

type: B

temperature units: °C

emf units: mV

range: 0.000, 630.615, 6

0.000000000000E+00
 -0.246508183460E-03
 0.590404211710E-05
 -0.132579316360E-08
 0.156682919010E-11
 -0.169445292400E-14
 0.629903470940E-18

range: 630.615, 1820.000, 8

-0.389381686210E+01
 0.285717474700E-01
 -0.848851047850E-04
 0.157852801640E-06
 -0.168353448640E-09
 0.111097940130E-12
 -0.445154310330E-16
 0.989756408210E-20
 -0.937913302890E-24

* This section contains coefficients of approximate inverse
 * functions for type B thermocouples for the subranges of
 * temperature and voltage listed below. The range of errors of
 * the approximate inverse function for each subrange is also given.
 * The coefficients are in units of °C and mV and are listed in
 * the order of constant term up to the highest order.

* The equation is of the form $t_{90} = d_0 + d_1 * E + d_2 * E^2 + \dots$
 * $+ d_n * E^n$,

* where E is in mV and t_{90} is in °C.

Temperature range (°C)	Voltage range (mV)	Error range (°C)
250. to 700.	0.291 to 2.431	-0.02 to 0.03
700. to 1800.	2.431 to 13.820	-0.01 to 0.02

Inverse coefficients for type B:

Temperature	250.	700.
Range:	700.	1820.
Voltage	0.291	2.431
Range:	2.431	13.820

```

    9.8423321E+01  2.1315071E+02
    6.9971500E+02  2.8510504E+02
   -8.4765304E+02 -5.2742887E+01
    1.0052644E+03  9.9160804E+00
   -8.3345952E+02 -1.2965303E+00
    4.5508542E+02  1.1195870E-01
   -1.5523037E+02 -6.0625199E-03
    2.9886750E+01  1.8661696E-04
   -2.4742860E+00 -2.4878585E-06

```

```

Error      -0.02      -0.01
Range:     0.03      0.02

```

* This section contains coefficients for type E thermocouples for
* the two subranges of temperature listed below. The coefficients
* are in units of °C and mV and are listed in the order of constant
* term up to the highest order. The equation is of the form
* $E = \sum_{i=0}^n c_i t^i$.

```

*
*      Temperature Range (°C)
*      -270.000 to 0.000
*      0.000 to 1000.000

```

name: reference function on ITS-90

type: E

temperature units: °C

emf units: mV

range: -270.000, 0.000, 13

```

    0.0000000000000E+00
    0.586655087080E-01
    0.454109771240E-04
   -0.779980486860E-06
   -0.258001608430E-07
   -0.594525830570E-09
   -0.932140586670E-11
   -0.102876055340E-12
   -0.803701236210E-15
   -0.439794973910E-17
   -0.164147763550E-19
   -0.396736195160E-22
   -0.558273287210E-25
   -0.346578420130E-28

```

range: 0.000, 1000.000, 10

```

    0.0000000000000E+00
    0.586655087100E-01
    0.450322755820E-04
    0.289084072120E-07
   -0.330568966520E-09
    0.650244032700E-12
   -0.191974955040E-15
   -0.125366004970E-17
    0.214892175690E-20
   -0.143880417820E-23
    0.359608994810E-27

```

* This section contains coefficients of approximate inverse

* functions for type E thermocouples for the subranges of
 * temperature and voltage listed below. The range of errors of
 * the approximate inverse function for each subrange is also given.
 * The coefficients are in units of °C and mV and are listed in
 * the order of constant term up to the highest order.
 * The equation is of the form $t_{90} = d_0 + d_1 * E + d_2 * E^2 + \dots$
 * $+ d_n * E^n$,
 * where E is in mV and t_{90} is in °C.

Temperature Range (°C)	Voltage range (mV)	Error range (°C)
-200. to 0.	-8.825 to 0.000	-0.01 to 0.03
0. to 1000.	0.000 to 76.373	-0.02 to 0.02

 Inverse coefficients for type E:

Temperature	-200.	0.
Range:	0.	1000.
Voltage	-8.825	0.000
Range:	0.000	76.373
	0.00000000E+00	0.00000000E+00
	1.6977288E+01	1.7057035E+01
	-4.3514970E-01	-2.3301759E-01
	-1.5859697E-01	6.5435585E-03
	-9.2502871E-02	-7.3562749E-05
	-2.6084314E-02	-1.7896001E-06
	-4.1360199E-03	8.4036165E-08
	-3.4034030E-04	-1.3735879E-09
	-1.1564890E-05	1.0629823E-11
	0.00000000E+00	-3.2447087E-14
Error	-0.01	-0.02
Range:	0.03	0.02

* This section contains coefficients for type J thermocouples for
 * the two subranges of temperature listed below. The coefficients
 * are in units of °C and mV and are listed in the order of constant
 * term up to the highest order. The equation is of the form
 * $E = \sum(i=0 \text{ to } n) c_i t^i$.

Temperature Range (°C)
-210.000 to 760.000
760.000 to 1200.000

name: reference function on ITS-90

type: J

temperature units: °C

emf units: mV

range: -210.000, 760.000, 8

0.00000000000000E+00
0.503811878150E-01
0.304758369300E-04
-0.856810657200E-07
0.132281952950E-09

```

-0.170529583370E-12
 0.209480906970E-15
-0.125383953360E-18
 0.156317256970E-22
range: 760.000, 1200.000, 5
 0.296456256810E+03
-0.149761277860E+01
 0.317871039240E-02
-0.318476867010E-05
 0.157208190040E-08
-0.306913690560E-12

```

```
*****
```

```

* This section contains coefficients of approximate inverse
* functions for type J thermocouples for the subranges of
* temperature and voltage listed below. The range of errors of
* the approximate inverse function for each subrange is also given.
* The coefficients are in units of °C and mV and are listed in
* the order of constant term up to the highest order.
* The equation is of the form  $t_{90} = d_0 + d_1 * E + d_2 * E^2 + \dots$ 
*   +  $d_n * E^n$ ,
* where E is in mV and  $t_{90}$  is in °C.
*

```

Temperature range (°C)	Voltage range (mV)	Error range (°C)
-210. to 0.	-8.095 to 0.000	-0.05 to 0.03
0. to 760.	0.000 to 42.919	-0.04 to 0.04
760. to 1200	42.919 to 69.553	-0.04 to 0.03

```
*****
```

```
Inverse coefficients for type J:
```

Temperature	-210.	0.	760.
Range:	0.	760.	1200.
Voltage	-8.095	0.000	42.919
Range:	0.000	42.919	69.553
	0.0000000E+00	0.000000E+00	-3.11358187E+03
	1.9528268E+01	1.978425E+01	3.00543684E+02
	-1.2286185E+00	-2.001204E-01	-9.94773230E+00
	-1.0752178E+00	1.036969E-02	1.70276630E-01
	-5.9086933E-01	-2.549687E-04	-1.43033468E-03
	-1.7256713E-01	3.585153E-06	4.73886084E-06
	-2.8131513E-02	-5.344285E-08	0.00000000E+00
	-2.3963370E-03	5.099890E-10	0.00000000E+00
	-8.3823321E-05	0.000000E+00	0.00000000E+00
Error	-0.05	-0.04	-0.04
Range:	0.03	0.04	0.03

```
*****
```

```

* This section contains coefficients for type K thermocouples for
* the two subranges of temperature listed below. The coefficients
* are in units of °C and mV and are listed in the order of constant
* term up to the highest order. The equation below 0 °C is of the form
*  $E = \sum(i=0 \text{ to } n) c_i t^i$ .
*

```

```

* The equation above 0 °C is of the form
*  $E = \sum_{i=0}^n c_i t^i + a_0 \exp(a_1 (t - a_2)^2)$ .
*
*   Temperature Range (°C)
*   -270.000 to 0.000
*   0.000 to 1372.000
*****
name: reference function on ITS-90
type: K
temperature units: °C
emf units: mV
range: -270.000, 0.000, 10
  0.0000000000000E+00
  0.394501280250E-01
  0.236223735980E-04
 -0.328589067840E-06
 -0.499048287770E-08
 -0.675090591730E-10
 -0.574103274280E-12
 -0.310888728940E-14
 -0.104516093650E-16
 -0.198892668780E-19
 -0.163226974860E-22
range: 0.000, 1372.000, 9
 -0.176004136860E-01
  0.389212049750E-01
  0.185587700320E-04
 -0.994575928740E-07
  0.318409457190E-09
 -0.560728448890E-12
  0.560750590590E-15
 -0.320207200030E-18
  0.971511471520E-22
 -0.121047212750E-25
exponential:
a0 = 0.118597600000E+00
a1 = -0.118343200000E-03
a2 = 0.126968600000E+03

*****
* This section contains coefficients of approximate inverse
* functions for type K thermocouples for the subranges of
* temperature and voltage listed below. The range of errors of
* the approximate inverse function for each subrange is also given.
* The coefficients are in units of °C and mV and are listed in
* the order of constant term up to the highest order.
* The equation is of the form  $t_{90} = d_0 + d_1 * E + d_2 * E^2 + \dots$ 
*   +  $d_n * E^n$ ,
* where E is in mV and  $t_{90}$  is in °C.
*
*   Temperature           Voltage           Error
*   range                 range           range
*   (°C)                  (mV)           (°C)
*   -200. to 0.           -5.891 to 0.000  -0.02 to 0.04
*   0. to 500.            0.000 to 20.644  -0.05 to 0.04
*   500. to 1372.        20.644 to 54.886  -0.05 to 0.06
*****
Inverse coefficients for type K:

```

Temperature	-200.	0.	500.
Range:	0.	500.	1372.
Voltage	-5.891	0.000	20.644
Range:	0.000	20.644	54.886
	0.0000000E+00	0.000000E+00	-1.318058E+02
	2.5173462E+01	2.508355E+01	4.830222E+01
	-1.1662878E+00	7.860106E-02	-1.646031E+00
	-1.0833638E+00	-2.503131E-01	5.464731E-02
	-8.9773540E-01	8.315270E-02	-9.650715E-04
	-3.7342377E-01	-1.228034E-02	8.802193E-06
	-8.6632643E-02	9.804036E-04	-3.110810E-08
	-1.0450598E-02	-4.413030E-05	0.000000E+00
	-5.1920577E-04	1.057734E-06	0.000000E+00
	0.0000000E+00	-1.052755E-08	0.000000E+00
Error	-0.02	-0.05	-0.05
Range:	0.04	0.04	0.06

* This section contains coefficients for type N thermocouples for
 * the two subranges of temperature listed below. The coefficients
 * are in units of °C and mV and are listed in the order of constant
 * term up to the highest order. The equation is of the form
 * $E = \sum_{i=0 \text{ to } n} c_i t^i$.

*

* Temperature Range (°C)

* -270.000 to 0.000

* 0.000 to 1300.000

name: reference function on ITS-90

type: N

temperature units: °C

emf units: mV

range: -270.000, 0.000, 8

0.0000000000000E+00

0.261591059620E-01

0.109574842280E-04

-0.938411115540E-07

-0.464120397590E-10

-0.263033577160E-11

-0.226534380030E-13

-0.760893007910E-16

-0.934196678350E-19

range: 0., 1300., 10

0.0000000000000E+00

0.259293946010E-01

0.157101418800E-04

0.438256272370E-07

-0.252611697940E-09

0.643118193390E-12

-0.100634715190E-14

0.997453389920E-18

-0.608632456070E-21

0.208492293390E-24

-0.306821961510E-28


```

*****
* This section contains coefficients of approximate inverse
* functions for type N thermocouples for the subranges of
* temperature and voltage listed below. The range of errors of
* the approximate inverse function for each subrange is also given.
* The coefficients are in units of °C and mV and are listed in
* the order of constant term up to the highest order.
* The equation is of the form  $t_{90} = d_0 + d_1 \cdot E + d_2 \cdot E^2 + \dots$ 
*   +  $d_n \cdot E^n$ ,
* where E is in mV and  $t_{90}$  is in °C.
*

```

Temperature range (°C)	Voltage range (mV)	Error range (°C)
-200. to 0.	-3.990 to 0.000	-0.02 to 0.03
0. to 600.	0.000 to 20.613	-0.02 to 0.03
600. to 1300.	20.613 to 47.513	-0.04 to 0.02

Inverse coefficients for type N:

Temperature	-200.	0.	600.
Range:	0.	600.	1300.
Voltage	-3.990	0.000	20.613
Range:	0.000	20.613	47.513
	0.0000000E+00	0.000000E+00	1.972485E+01
	3.8436847E+01	3.86896E+01	3.300943E+01
	1.1010485E+00	-1.08267E+00	-3.915159E-01
	5.2229312E+00	4.70205E-02	9.855391E-03
	7.2060525E+00	-2.12169E-06	-1.274371E-04
	5.8488586E+00	-1.17272E-04	7.767022E-07
	2.7754916E+00	5.39280E-06	0.000000E+00
	7.7075166E-01	-7.98156E-08	0.000000E+00
	1.1582665E-01	0.000000E+00	0.000000E+00
	7.3138868E-03	0.000000E+00	0.000000E+00
Error	-0.02	-0.02	-0.04
Range:	0.03	0.03	0.02

```

*****
* This section contains coefficients for type R thermocouples for
* the two subranges of temperature listed below. The coefficients
* are in units of °C and mV and are listed in the order of constant
* term up to the highest order. The equation is of the form
*  $E = \sum_{i=0}^n c_i t^i$ .
*

```

Temperature Range (°C)
-50.000 to 1064.180
1064.180 to 1664.500
1664.500 to 1768.100

```

name: reference function on ITS-90
type: R
temperature units: °C
emf units: mV
range: -50.000, 1064.180, 9
0.000000000000E+00

```

```

0.528961729765E-02
0.139166589782E-04
-0.238855693017E-07
0.356916001063E-10
-0.462347666298E-13
0.500777441034E-16
-0.373105886191E-19
0.157716482367E-22
-0.281038625251E-26
range: 1064.180, 1664.500, 5
0.295157925316E+01
-0.252061251332E-02
0.159564501865E-04
-0.764085947576E-08
0.205305291024E-11
-0.293359668173E-15
range: 1664.5, 1768.1, 4
0.152232118209E+03
-0.268819888545E+00
0.171280280471E-03
-0.345895706453E-07
-0.934633971046E-14

```

```

*****
* This section contains coefficients of approximate inverse
* functions for type R thermocouples for the subranges of
* temperature and voltage listed below. The range of errors of
* the approximate inverse function for each subrange is also given.
* The coefficients are in units of °C and mV and are listed in
* the order of constant term up to the highest order.
* The equation is of the form  $t_{90} = d_0 + d_1 * E + d_2 * E^2 + \dots$ 
*   +  $d_n * E^n$ ,
* where E is in mV and  $t_{90}$  is in °C.
*

```

Temperature range (°C)	Voltage range (mV)	Error range (°C)
-50. to 250.	-0.226 to 1.923	-0.02 to 0.02
250. to 1200.	1.923 to 13.228	-0.005 to 0.005
1064. to 1664.5	11.361 to 19.739	-0.0005 to 0.001
1664.5 to 1768.1	19.739 to 21.103	-0.001 to 0.002

Inverse coefficients for type R:

Temperature	-50.	250.	1064.	1664.5
Range:	250.	1200.	1664.5	1768.1
Voltage	-0.226	1.923	11.361	19.739
Range:	1.923	13.228	19.739	21.103

```

0.0000000E+00 1.334584505E+01 -8.199599416E+01 3.406177836E+04
1.8891380E+02 1.472644573E+02 1.553962042E+02 -7.023729171E+03
-9.3835290E+01 -1.844024844E+01 -8.342197663E+00 5.582903813E+02
1.3068619E+02 4.031129726E+00 4.279433549E-01 -1.952394635E+01
-2.2703580E+02 -6.249428360E-01 -1.191577910E-02 2.560740231E-01
3.5145659E+02 6.468412046E-02 1.492290091E-04 0.000000000E+00
-3.8953900E+02 -4.458750426E-03 0.000000000E+00 0.000000000E+00
2.8239471E+02 1.994710149E-04 0.000000000E+00 0.000000000E+00
-1.2607281E+02 -5.313401790E-06 0.000000000E+00 0.000000000E+00

```

```

3.1353611E+01 6.481976217E-08 0.000000000E+00 0.000000000E+00
-3.3187769E+00 0.000000000E+00 0.000000000E+00 0.000000000E+00

```

```

Error      -0.02      -0.005      -0.0005      -0.001
Range:     0.02      0.005      0.001      0.002

```

```
*****
```

```

* This section contains coefficients for type S thermocouples for
* the two subranges of temperature listed below. The coefficients
* are in units of °C and mV and are listed in the order of constant
* term up to the highest order. The equation is of the form
*  $E = \sum_{i=0}^n c_i t^i$ .

```

```

*
* Temperature Range (°C)
* -50.000 to 1064.180
* 1064.180 to 1664.500
* 1664.500 to 1768.100

```

```
*****
```

```
name: reference function on ITS-90
```

```
type: S
```

```
temperature units: °C
```

```
emf units: mV
```

```
range: -50.000, 1064.180, 8
```

```

0.0000000000000E+00
0.540313308631E-02
0.125934289740E-04
-0.232477968689E-07
0.322028823036E-10
-0.331465196389E-13
0.255744251786E-16
-0.125068871393E-19
0.271443176145E-23

```

```
range: 1064.180, 1664.500, 4
```

```

0.132900444085E+01
0.334509311344E-02
0.654805192818E-05
-0.164856259209E-08
0.129989605174E-13

```

```
range: 1664.5, 1768.1, 4
```

```

0.146628232636E+03
-0.258430516752E+00
0.163693574641E-03
-0.330439046987E-07
-0.943223690612E-14

```

```
*****
```

```

* This section contains coefficients of approximate inverse
* functions for type S thermocouples for the subranges of
* temperature and voltage listed below. The range of errors of
* the approximate inverse function for each subrange is also given.
* The coefficients are in units of °C and mV and are listed in
* the order of constant term up to the highest order.
* The equation is of the form  $t_{90} = d_0 + d_1 E + d_2 E^2 + \dots$ 

```

```

* +  $d_n E^n$ ,
* where E is in mV and  $t_{90}$  is in °C.

```

```

* Temperature      Voltage      Error
* range            range        range

```

```

*          (°C)                (mV)                (° C)
*   -50. to 250.        -0.235 to 1.874        -0.02 to 0.02
*   250. to 1200.        1.874 to 11.950        -0.01 to 0.01
*   1064. to 1664.5     10.332 to 17.536        -0.0002 to 0.0002
*   1664.5 to 1768.1   17.536 to 18.693        -0.002 to 0.002

```

Inverse coefficients for type S:

Temperature	-50.	250.	1064.	1664.5
Range:	250.	1200.	1664.5	1768.1
Voltage	-0.235	1.874	10.332	17.536
Range:	1.874	11.950	17.536	18.693
	0.00000000E+00	1.291507177E+01	-8.087801117E+01	5.333875126E+04
	1.84949460E+02	1.466298863E+02	1.621573104E+02	-1.235892298E+04
	-8.00504062E+01	-1.534713402E+01	-8.536869453E+00	1.092657613E+03
	1.02237430E+02	3.145945973E+00	4.719686976E-01	-4.265693686E+01
	-1.52248592E+02	-4.163257839E-01	-1.441693666E-02	6.247205420E-01
	1.88821343E+02	3.187963771E-02	2.081618890E-04	0.000000000E+00
	-1.59085941E+02	-1.291637500E-03	0.000000000E+00	0.000000000E+00
	8.23027880E+01	2.183475087E-05	0.000000000E+00	0.000000000E+00
	-2.34181944E+01	-1.447379511E-07	0.000000000E+00	0.000000000E+00
	2.79786260E+00	8.211272125E-09	0.000000000E+00	0.000000000E+00
Error	-0.02	-0.01	-0.0002	-0.002
Range:	0.02	0.01	0.0002	0.002

```

* This section contains coefficients for type T thermocouples for
* the two subranges of temperature listed below. The coefficients
* are in units of °C and mV and are listed in the order of constant
* term up to the highest order. The equation is of the form
* E = sum(i=0 to n) c_i t^i.

```

```

*
* Temperature Range (°C)
*   -270.000 to 0.000
*     0.000 °C to 400.000

```

name: reference function on ITS-90

type: T

temperature units: °C

emf units: mV

range: -270.000, 0.000, 14

```

0.0000000000000E+00
0.387481063640E-01
0.441944343470E-04
0.118443231050E-06
0.200329735540E-07
0.901380195590E-09
0.226511565930E-10
0.360711542050E-12
0.384939398830E-14
0.282135219250E-16
0.142515947790E-18
0.487686622860E-21
0.107955392700E-23
0.139450270620E-26
0.797951539270E-30

```

```

range: 0.000, 400.000, 8
0.0000000000000E+00
0.387481063640E-01
0.332922278800E-04
0.206182434040E-06
-0.218822568460E-08
0.109968809280E-10
-0.308157587720E-13
0.454791352900E-16
-0.275129016730E-19

```

```
*****
```

```

* This section contains coefficients of approximate inverse
* functions for type T thermocouples for the subranges of
* temperature and voltage listed below. The range of errors of
* the approximate inverse function for each subrange is also given.
* The coefficients are in units of °C and mV and are listed in
* the order of constant term up to the highest order.
* The equation is of the form  $t_{90} = d_0 + d_1 * E + d_2 * E^2 + \dots$ 
*   +  $d_n * E^n$ ,
* where E is in mV and  $t_{90}$  is in °C.

```

```

*
*   Temperature           Voltage           Error
*   range                 range           range
*   (°C)                  (mV)           (° C)
*   -200. to 0.          -5.603 to 0.000   -0.02 to 0.04
*   .0 to 400.          0.000 to 20.872   -0.03 to 0.03

```

```
*****
Inverse coefficients for type T:
```

```

Temperature  -200.           0.
Range:        0.           400.

Voltage      -5.603         0.000
Range:       0.000         20.872

0.0000000E+00  0.0000000E+00
2.5949192E+01  2.5928000E+01
-2.1316967E-01 -7.602961E-01
7.9018692E-01  4.637791E-02
4.2527777E-01 -2.165394E-03
1.3304473E-01  6.048144E-05
2.0241446E-02 -7.293422E-07
1.2668171E-03  0.0000000E+00

Error        -0.02         -0.03
Range:       0.04         0.03

```